SyncMaster 400CX-2, 400CXN-2, 460CX-2, 460CXN-2

LCD Display

User Manual

Downloaded From TV-Manual.com Manuals

Safety Instructions

Notational

Note

These safety instructions must be followed to ensure your safety and prevent property damage.

Make sure to read the instructions carefully and use the product in the correct manner.

Warning / Caution

Failure to follow directions noted by this symbol could result in bodily harm or damage to the equipment.

Note

Prohibited	Important to read and understand at all times
Do not disassemble	Disconnect the plug from the outlet
Do not touch	Ground to prevent an electric shock

Power

When not used for extended period of time, set your computer to DPM.

If using a screen saver, set it to active screen mode.

The images here are for reference only, and are not applicable in all cases (or countries).

Shortcut to Anti-Afterimage Instructions

Do not use a damaged power cord or plug or a damaged or loose power outlet.

- Otherwise, this may result in electric shock or fire.

Do not touch the power plug with wet hands when removing or plugging the plug into the outlet.

- Otherwise, this may result in electric shock.



Make sure to connect the power cord to a grounded power outlet.

- Otherwise, it may result in electric shock or personal injury.

Downloaded From TV-Manual.com Manuals



Ensure that the power plug is plugged into the power outlet firmly and correctly.

- Otherwise, this may result in fire.

Do not forcefully bend or pull the power plug and do not place any heavy material on it.

- Otherwise, this may result in fire.

Do not connect multiple appliances to the same power outlet.

- Otherwise, this may cause fire due to overheating.

Do not disconnect the power cord while using the product.

- Otherwise, this may result in damage to the product due to electric shock.

To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

- Otherwise, this may cause electric shock or fire.

Use only the power cord provided by our company. Do not use the provided power cord of another product.

- Otherwise, this may result in fire or electric shock.

Installation

Be sure to contact an authorized Service Center when installing your monitor in a location with heavy dust, high or low temperatures, high humidity, and exposed to chemical substances and where it operates for 24 hours such as at airports, train stations etc.

Failure to do so may cause serious damage to your monitor.

Ensure that at least two persons lift and move the product.

- Otherwise, it may be dropped and cause personal injury, and/or damage the product.

When installing the product in a cabinet or rack, make sure that the front end of the bottom of the product does not project out.

- Otherwise, it may fall or cause personal injury.
- Use a cabinet or rack of a size appropriate to the product.

DO NOT PLACE CANDLES, MOSQUITO REPELLANT, CIGARETTES AND ANY HEATING APPLIANCES NEAR THE PRODUCT.

- Otherwise, this may result in fire.

Downloaded From TV-Manual.com Manuals

Keep heating appliances as far away from the power cord or the product as possible.

- Otherwise, this may result in electric shock or fire.

Do not install it in a badly ventilated location such as a bookcase or closet.

- Otherwise, this may result in fire due to an increase in the internal temperature.

When putting the product down, make sure to put it down softly.

- Otherwise, this may result in damage to the screen display.

Do not place the front of the product on the floor.

- Otherwise, this may result in damage to the screen display.

Ensure that an authorized installation company installs the wall mount.

- Otherwise, it may fall and cause personal injury.
- Make sure to install the specified wall mount.

Install your product in a well ventilated location. Ensure that there is a clearance of more than 4 inches (10 cm) from the wall.

- Otherwise, it may result in fire due to an increase in the internal temperature.

Bend the outdoor antenna cable downwards at the location where it goes in so that rainwater does not flow in.

- If rainwater enters the product, it may result in electric shock or fire.

Install the antenna far away from any high voltage cables.

- If the antenna touches or falls onto a high voltage cable, it may result in electric shock or fire.

Ensure that the packaging vinyl is kept away from children.

- Otherwise, it may result in serious harm (suffocation) if children play with it.

If the height of your monitor is adjustable, do not place any object or part of your body on the stand when lowering it.

- This may cause damage to the product or the person carrying it.

Downloaded From TV-Manual.com Manuals

Clean

When cleaning the monitor case or the surface of the TFT-LCD screen, wipe with a slightly moistened, soft cloth.

Do not spray cleaner directly onto the surface of the product.

- Otherwise, this may result in the discoloration and distortion of the structure and the screen surface may peel off.



When cleaning the power plug pins or dusting the power outlet, clean it with a dry cloth.

- Otherwise, it may result in fire.

When cleaning the product, make sure to disconnect the power cord.

- Otherwise, it may result in electric shock or fire.

When cleaning the product, disconnect the power cord and clean it with a slightly moistened, soft cloth.

- (Do not use chemicals such as wax, benzene, alcohol, thinner, mosquito repellant, lubricant, or cleaner.) These may change the appearance of the product surface and peel off the indication labels on the product.

Since the product housing is easily scratched, make sure to use the specified cloth only.

When cleaning the product, do not spray water directly onto the main body of the product.

- Ensure that water does not enter the product and that it is not wet.
- Otherwise, this may result in electric shock, fire or a malfunction.

Others

The product is a high voltage product. Do not disassemble, repair or modify the product yourself.

- Otherwise, this may result in electric shock or fire. If the product needs to be repaired, contact a Service Center.



If there is a strange smell or a strange sound or smoke is coming from the product, disconnect the power plug immediately and contact a Service Center.

- Otherwise, this may result in electric shock or fire.

Do not place this product in a location exposed to moisture, dust, smoke, water, or in a car.

- Otherwise, this may result in electric shock or fire.

Downloaded From TV-Manual.com Manuals

When you drop the product or the case is broken, turn the power off and disconnect the power cord. Contact a Service Center.

- Otherwise, this may result in electric shock or fire.

If thunder or lightning is occurring, do not touch the power cord or antenna cable.

- Otherwise, this may result in electric shock or fire.

Do not try to move the monitor by pulling only the wire or the signal cable.

- Otherwise, it may fall and result in electric shock, damage to the product or fire due to damage to the cable.

Do not lift or move the product back and forwards or right and left while only holding the power cord or signal cables.

- Otherwise, it may fall and result in electric shock, damage to the product or fire due to damage to the cable.

Make sure that the ventilating opening is not blocked by a table or curtain.

- Otherwise, it may result in fire due to an increase in the internal temperature.

Do not place any containers containing water, vases, flowerpots, medicines as well as any metal on the product.

- If water or a foreign material enters the product, disconnect the power cord and contact a Service Center.
- This may result in a product malfunction, electric shock, or fire.

Do not use or keep combustible spray or flammable material near the product.

- Otherwise, this may result in an explosion or fire.

Do not insert any metal, such as chopsticks, coins, pins and steel, or flammable objects, such as matches or paper, inside the product (through the ventilating openings, input and output terminals, etc).

- If water or foreign material enters the product, disconnect the power cord and contact a Service Center.
- Otherwise, this may result in electric shock or fire.

When using a fixed screen for a long time, an afterimage or stain may occur.

- If you are not using your product for a long period of time, put it into sleep mode or use a moving screen saver.

Set a resolution and frequency appropriate to the product.

- Otherwise, your eyesight may be damaged.

Downloaded From TV-Manual.com Manuals

When using headphones or earphones, do not turn the volume too high.

- Having the sound too loud may damage your hearing.

To avoid eyestrain, do not sit too close to the product.

Take a rest for at least five (5) minutes after using the monitor for one (1) hour.

This reduces eye fatigue.

Do not install it in an unstable location such as an unstable rack or uneven surface or a location exposed to vibrations.

- Otherwise, it may fall and cause personal injury and/or damage the product.
- If you use the product in a location exposed to vibrations, it may damage the product and result in fire.

When moving the product, turn the power off and disconnect the power plug, antenna cable, and all the cables connected to the product.

- Otherwise, it may result in electric shock or fire.

Ensure that children do not hang onto the product or climb up onto the product.

- The product may fall and cause personal injury or death.

If you do not use the product for a long period of time, disconnect the power cord from the power outlet.

- Otherwise, this may result in overheating or fire due to dust, and may result in fire due to electric shock or leakage.

Do not place any heavy items or toys or confectionery, such as cookies etc. that may attract the attention of children and to the product.

- Your children may hang onto the product causing it to fall and this may result in personal injury or death.

Be careful that children do not place the battery in their mouths when removed from the remote control. Place the battery in a location that children or infants cannot reach.

- If children have had the battery in their mouths, consult your doctor immediately.



When replacing the battery, insert it with the right polarity (+, -).

- Otherwise, the battery may become damaged or it may cause fire, personal injury or damage due to leakage of the internal liquid.

Downloaded From TV-Manual.com Manuals

Use only the specified standardized batteries, and do not use a new battery and a used battery at the same time.

- Otherwise, the batteries may be damaged or cause fire, personal injury or damage due to a leakage of the internal liquid.

The batteries (and rechargeable batteries) are not ordinary refuse and must be returned for recycling purposes. The customer is responsible for returning the used or rechargeable batteries for recycling.

- The customer can return used or rechargeable batteries to a nearby public recycling center or to a store selling the same type of the battery or rechargeable battery.

Do not place the product in a location exposed to direct sunlight or near any heat such as a fire or heater.

- This may reduce the lifetime of the product, and may result in fire.

Do not drop any objects onto the product or cause any impact to the product.

- Otherwise, this may result in electric shock or fire.

Do not use a humidifier near the product.

- Otherwise, this may result in electric shock or fire.



When there is a gas leak, do not touch the product or the power plug; ventilate immediately.

- If a spark occurs, it may cause an explosion or fire.

If the product has been turned on for a long time, the display panel becomes hot. Do not touch it.

Keep the small accessories in a location out of the reach of children.

Be careful when adjusting the angle of the product or the height of the stand.

- This may result in personal injury as your hand or fingers may become caught.
- Also, if you tilt the product too far, it may fall and cause personal injury.

Do not install the product in a location low enough for children to reach.

- Otherwise, it may fall and result in personal injury.

Downloaded From TV-Manual.com Manuals

- Since the front part of the product is heavy, install the product on a level and stable surface.

Do not put any heavy objects on the product.

- This may result in personal injury and/or damage to the product.

Downloaded From TV-Manual.com Manuals

Introduction

Package Contents

Note

Please make sure the following items are included with your LCD Display.

If any items are missing, contact your dealer.

Contact a local dealer to buy optional items.

Checking the Contents of the Package



Remove the lock from the package box, as shown in the figure above.

Lift up the package box by holding the grooves on both sides of the package box.



Check the contents of the package.

Remove the Styrofoam and vinyl cover.

Note

- After unpacking the package, make sure to check the contents of the package.
- Make sure to keep the package box for transporting the product in the future.

Unpacking

LCD Display

Downloaded From TV-Manual.com Manuals

Manuals

Quick Setup Guide

Warranty Card

(Not available in all locations)

User's Guide

MagicInfo Software CD,
MagicInfo Manual CD

(Applicable to the CXN-2 model only)

Cables

Power Cord

Others

Remote Control

Batteries (AAA X 2)

(Not available in all locations)

HDD Cover
(Applicable to the CXN-2 model only)

Cleaning Cloth

Sold separately



DVI Cable

LAN Cable



Wall Mount KIT

Downloaded From TV-Manual.com Manuals

Sold separately

(Applicable to the CXN-2 model only)



Component to D-sub Cable

Semi Stand KIT

D-Sub Cable

Note

Cleaning Cloth is only provided for highly polished black products as a product feature.

Your LCD Display

Front



1. *MENU button [MENU]*

   Opens the on-screen menu and exits from the menu. Also use to exit the OSD menu or return to the previous menu.

2. *Navigate buttons (Down-Up buttons) / Channel buttons*

   Moves from one menu item to another vertically or adjusts selected menu values.

   / When OSD is not on the screen, press the button to adjust channels.

3. *Adjust buttons (Left-Right buttons) / Volume buttons*

   Moves from one menu item to another horizontally or adjusts selected menu values. When OSD is not on the screen, press the button to adjust volume.

4. *ENTER button [ENTER]*

   Activates a highlighted menu item.

Downloaded From TV-Manual.com Manuals

5 *SOURCE button [SOURCE]*

Switches from PC mode to Video mode. Selects the input source that an external device is connected to.

[**PC**] → [**DVI**] → [**AV**] → [Component] → [HDMI]→ [**MagicInfo**] → [**TV**]

Note

MagicInfo supports the CXN-2 model only.

6 *D.MENU*

Opens the on-screen D.MENU.

7 *Power button [⏻]*

Use this button for turning the LCD Display on and off.

8 *Brightness Sensor* (Optional)

Automatically detects the surrounding brightness.

This function is activated only on the models equipped with an auto brightness sensor.

9 *Power indicator*

Shows PowerSaver mode by blinking green

Note

See PowerSaver described in the manual for further information regarding power saving functions. For energy conservation, turn your LCD Display OFF when it is not needed or when leaving it unattended for long periods.

10 *Remote Control Sensor*

Aim the remote control towards this spot on the LCD Display.

Rear

Note

For detailed information concerning cable connections, refer to Connecting Cables under Setup. The LCD Display 's configuration at the back may vary slightly depending on the model.

Downloaded From TV-Manual.com Manuals



A



1 *POWER S/W ON [|] / OFF [O]*

Switches the LCD Display On/Off.

2 *POWER*

The power cord plugs into the LCD Display and the wall outlet.

B



3 *RS232C OUT/IN (RS232C Serial PORT)*

MDC(Multiple Display Control) Program Port

4 *RGB/COMPONENT IN (PC Video Connection Terminal)*

- Use a D-Sub Cable (15 pin D-Sub) - PC mode (Analog PC)
- Connect the RGB/COMPONENT IN port on the monitor to the COMPONENT port on the external device using the D-SUB to COMPONENT cable.
- Connect the RGB/COMPONENT IN port on the monitor to the BNC port on the PC using the D-SUB to BNC cable.

5 *DVI IN (PC Video Connection Terminal)*

Downloaded From TV-Manual.com Manuals

Use a DVI Cable (DVI-D to DVI-D) - DVI mode (Digital PC)

C



6 *DVI/RGB/HDMI AUDIO IN(PC/DVI/HDMI(PC) Audio connection terminal(input))*

7 *AV / COMPONENT AUDIO IN [R- AUDIO- L]*

Connect the port of the DVD, VCR (DVD / DTV Set-Top Box) to the [R- AUDIO - L] port of the LCD Display.

8 *DVI OUT*

- Connect a monitor to another monitor through a DVI cable.
- Connect the DVI OUT port on the monitor to the HDMI IN port on the other monitor using the DVI to HDMI cable.
- DVI, HDMI and network signals sent via the DVI OUT port are displayed on the second display which has the DVI IN port.

D



9 *AV IN [VIDEO]*

Connect the [VIDEO] terminal of your monitor to the video output terminal of the external device using a VIDEO cable.

10 *AUDIO OUT*

Headphone/External speaker output terminal.

11 *HDMI IN*

Connect the HDMI terminal at the back of your LCD Display to the HDMI terminal of your digital output device using a HDMI cable.

Up to HDMI cable 1.0 can be supported.

E

Downloaded From TV-Manual.com Manuals



12 *COMMON INTERFACE*

This contains information on CAM inserted in the CI slot and displays it.

When not inserting CI CARD in some channels, **Scramble Signal** is displayed on the screen.

You can install the CAM anytime whether the TV is ON or OFF.

13 *SERVICE*

This is a reserved terminal used for servicing.

14 *ANT IN*

Connect the CATV cable or TV antenna cable to the " ANT IN" port on the rear side of the LCD Display. Make sure to use a TV antenna cable (sold separately) as the antenna cable.

F



15 *RGB OUT*

Note

(Applicable to the CXN-2 model only)

16 *LAN (LAN Connection Terminal)*

Note

(Applicable to the CXN-2 model only)

17 *USB(USB Connection Terminal)*

Keyboard / Mouse, Mass Storage Device Compatible.

Note

(Applicable to the CXN-2 model only)

G

Downloaded From TV-Manual.com Manuals



Kensington Lock

The Kensington Lock is a device used to physically fix the system when using it in a public place. The locking device has to be purchased separately. The appearance and locking method may differ from the illustration depending on the manufacturer. Refer to the manual provided with the Kensington Lock for proper use. The locking device has to be purchased separately.

Note

The location of the Kensington Lock may be different depending on the model.

Using the Anti-Theft Kensington Lock

1. Insert the locking device into the Kensington slot on the LCD Display (B) and turn it in the locking direction (A).
2. Connect the Kensington Lock cable.
3. Fix the Kensington Lock to a desk or a heavy stationary object.

Note

See Connecting Cables for further information regarding cable connections.

Remote Control

Note

The performance of the remote control may be affected by a TV or other electronic device operating near the LCD Display , causing a malfunction due to interference with the frequency.

Downloaded From TV-Manual.com Manuals



1. POWER
2. OFF
3. Number Buttons
4. DEL -/-- / GUIDE button
5. + VOL -
6. SOURCE
7. D.MENU
8. TOOLS
9. Up - Down Left - Right buttons
10. INFO
11. COLOR BUTTONS
12. TTX/MIX
13. MTS/DUAL
14. ENTER/PRE-CH
15. MUTE
16. CH/P
17. TV
18. MENU
19. RETURN
20. EXIT
21. MagicInfo

1. POWER	Turns the product On.
2. OFF	Turns the product Off.
3. Number Buttons	Press to change the channel.
4. DEL -/-- / GUIDE button	The "-" button is used to select Digital channels. For example, channel 4 - 1. Electronic Program Guide (EPG) display. - This fuction does not work for this LCD Display.
5. + VOL -	Adjusts the audio volume.
6. SOURCE	Press the button to change the input signal SOURCE. Changing the SOURCE is only allowed for external devices that are connected to the LCD Display at the time.
7. D.MENU	DTV menu display - This Function does not work for this LCD Display.

Downloaded From TV-Manual.com Manuals

8. TOOLS — Use to quickly select frequently used functions.

9. Up-Down Left-Right buttons — Moves from one menu item to another horizontally, vertically or adjusts selected menu values.

10. *i* INFO — Current picture information is displayed on the upper left corner of the screen.

11. COLOR BUTTONS — Press to add or delete channels and to store channels to the favorite channel list in the “Channel List” menu.

- This fuction does not work for this LCD Display.

12. TTX/MIX — TV channels provide written information services via teletext.

- This fuction does not work for this LCD Display.

- Teletext Buttons

For more information > TTX / MIX

13. MTS/DUAL — - This fuction does not work for this LCD Display.

MTS-

You can select MTS (Multichannel Television Stereo) mode.

	Audio Type	MTS/S_Mode	Default
FM Stereo	Mono	Mono	Manual Change
	Stereo	Mono ↔ Stereo	
	SAP	Mono ↔ SAP	Mono

DUAL-

STEREO/MONO, DUAL Ⅰ / DUAL Ⅱ and MONO/NICAM MONO/NICAM STEREO can be operated depending on the broadcasting type by using the DUAL button on the remote control while watching TV.

14. ENTER/PRE-CH — This button is used to return to the immediately previous channel.

- This fuction does not work for this LCD Display.

15. MUTE — Pauses (mutes) the audio output temporarily. This is displayed on the lower left corner of the screen.

The audio resumes if MUTE or - VOL + is pressed in the Mute mode.

16. ∨CH/P∧ — In **TV** mode, selects TV channels.

- This fuction does not work for this LCD Display.

17. TV — Selects the TV mode directly.

Downloaded From TV-Manual.com Manuals

- This fuction does not work for this LCD Display.

18. MENU	Opens the on-screen menu and exits from the menu or closes the adjustment menu.
19. RETURN	Returns to the previous menu.
20. EXIT	Exits from the menu screen.
21. MagicInfo	MagicInfo Quick Launch Button.

Mechanical Layout (400CX-2 ,400CXN-2)

Mechanical Layout



VESA Wall Mount Bracket Installation

- When installing VESA, make sure to comply with the international VESA standards.
- Purchasing VESA Bracket and Installation Information : Please contact your nearest SAMSUNG Distributor to place an order.
- At least 2 persons are needed in order to move the LCD Display.
- SAMSUNG is not responsible for any damage to the product or persons if you elect to install the unit on your own.

Downloaded From TV-Manual.com Manuals

Dimensions



Notice

For securing the bracket on a wall, use only machine screws of 6 mm diameter and 8 to 12 mm length.

Wall Bracket Installation

- Contact a technician for installing the wall bracket.
- SAMSUNG Electronics is not responsible for any damages to the product or persons if you elect to install the unit on your own.
- This product is for installing on cement walls. The product may not stay in place when installed on plaster or wood.

Components

Only use the components and accessories shipped with the wall mount.



Wall Bracket(1)	Hinge(Left 1, Right 1)	Plastic Hanger (4)	Screw (A)(11)	Screw (B)(4)	Anchor (11)

Wall Bracket Assembly

Note

There are two hinges(left and right). Use the correct one.

Downloaded From TV-Manual.com Manuals

1. Insert and tighten the Captive Screw in the direction of the arrow.

   When done, mount the wall bracket on the wall.



   There are two hinges(left and right). Use the correct one.

   A - Captive Screw
   B - Wall Bracket
   C - Hinge (Left)
   D - Hinge (Right)

2. Before drilling into the wall, check if the length between the two locking holes at the back of the product is correct.

   If the length is too short or long, loosen all or some of the 4screws on the wall bracket to adjust the length.



   A - Length between the two locking holes

3. Check the installation diagram and mark the drill points on the wall. Use the 5.0 mm bit to drill holes deeper than 35 mm. Fix each anchor in the corresponding hole. Match each of the brackets and hinge holes to the corresponding anchor holes and insert and tighten the 11 screws A.

Downloaded From TV-Manual.com Manuals



To mount the product on the wall bracket

The shape of the product may vary depending on the model. (The assemblies of the plastic hanger and the screw are the same)

1. Remove the 4 screws on the back of the product.



2. Insert screw B into the plastic hanger.



Notice

- Mount the product on the wall bracket and make sure it is properly fixed to the left and right plastic hangers.
- Be careful when installing the product on the bracket as fingers can be caught in the holes.
- Make sure the wall bracket is securely fixed to the wall, or the product may not stay in place after installation.

3. Tighten the 4 screws in step 2 (plastic hanger + screw B)to the rear holes of the product.

Downloaded From TV-Manual.com Manuals



4. Remove safety pin (3) and insert the 4 product holders into the corresponding bracket holes (1). Then place the product(2) so that it is firmly fixed to the bracket. Make sure to re-insert and tighten the safety pin (3) to securely hold the product to the bracket.



A - LCD Display
B - Wall Bracket
C - Wall

Wall Bracket Angle Adjustment

Adjust the bracket angle to -2° before installing it on the wall.



1. Fix the product to the wall bracket.
2. Hold the product at the top in the center and pull it forward (direction of the arrow) to adjust the angle.

Note

You can adjust the bracket angle between -2° and 15°.

Downloaded From TV-Manual.com Manuals



Make sure to use the top center, and not the left or the right side of the product to adjust the angle.

Mechanical Layout (460CX-2 ,460CXN-2)

Mechanical Layout



VESA Wall Mount Bracket Installation

- When installing VESA, make sure to comply with the international VESA standards.
- Purchasing VESA Bracket and Installation Information : Please contact your nearest SAMSUNG Distributor to place an order. After your order is placed, installation professionals will visit you and install the bracket.
- At least 2 persons are needed in order to move the LCD Display.
- SAMSUNG Electronics is not responsible for any damage to the product or persons if you elect to install the unit on your own.

Downloaded From TV-Manual.com Manuals

Dimensions



Notice

For securing the bracket on a wall, use only machine screws of 6 mm diameter and 8 to 12 mm length.

Wall Bracket Installation

- Contact a technician for installing the wall bracket.
- SAMSUNG Electronics is not responsible for any damage to the product or persons if you elect to install the unit on your own.
- This product is for installing on cement walls. The product may not stay in place when installed on plaster or wood.

Components

Only use the components and accessories shipped with the product.



Wall Bracket(1)	Hinge(Left 1, Right 1)	Plastic Hanger (4)	Screw (A)(11)	Screw (B)(4)	Anchor (11)

Wall Bracket Assembly

Note

There are two hinges(left and right). Use the correct one.

1. Insert and tighten the Captive Screw in the direction of the arrow.

Downloaded From TV-Manual.com Manuals

When done, mount the wall bracket on the wall.



There are two hinges(left and right). Use the correct one.

A - Captive Screw
B - Wall Bracket
C - Hinge (Left)
D - Hinge (Right)

2. Before drilling into the wall, check if the length between the two locking holes at the back of the product is correct.

   If the length is too short or long, loosen all or some of the 4screws on the wall bracket to adjust the length.



A - Length between the two locking holes

3. Check the installation diagram and mark the drill points on the wall. Use the 5.0 mm bit to drill holes deeper than 35 mm. Fix each anchor in the corresponding hole. Match each of the brackets and hinge holes to the corresponding anchor holes and insert and tighten the 11 screws A.

Downloaded From TV-Manual.com Manuals



To mount the product on the wall bracket

The shape of the product may vary depending on the model. (The assemblies of the plastic hanger and the screw are the same)

1. Remove the 4 screws on the back of the product.



2. Insert the screw B into the plastic hanger.



Notice

- Mount the product on the wall bracket and make sure it is properly fixed to the left and right plastic hangers.
- Be careful when installing the product on the bracket as fingers can be caught in the holes.
- Make sure the wall bracket is securely fixed to the wall, or the product may not stay in place after installation.

3. Tighten the 4 screws in step 2 (plastic hanger + screw B)to the rear holes of the product.

Downloaded From TV-Manual.com Manuals



4. Remove safety pin (3) and insert the 4 product holders into the corresponding bracket holes (1). Then place the product(2) so that it is firmly fixed to the bracket. Make sure to re-insert and tighten the safety pin (3) to securely hold the product to the bracket.



A - LCD Display
B - Wall Bracket
C - Wall

Wall Bracket Angle Adjustment

Adjust the bracket angle to -2° before installing it on the wall.



1. Fix the product to the wall bracket.
2. Hold the product at the top in the center and pull it forward (direction of the arrow) to adjust the angle.

Note

You can adjust the bracket angle between -2° and 15°.

Downloaded From TV-Manual.com Manuals



Make sure to use the top center, and not the left or the right side of the product to adjust the angle.

Downloaded From TV-Manual.com Manuals

Connections

Connecting a Computer

AV input devices such as DVD players, VCRs or camcorders as well as your computer can be connected to the LCD Display. For detailed information on connecting AV input devices, refer to the contents under Adjusting Your LCD Display.



1. Connect the power cord for your LCD Display to the power port on the back of the LCD Display. Turn on the power switch.
2. There are several ways to connect the computer to the monitor. Choose one from the following options:

   2-1 Using the D-sub (Analog) connector on the video card.

   - Connect the D-sub to the 15-pin, RGB port on the back of your LCD Display and the 15 pin D-sub Port on the computer.

   2-2 Using the DVI (Digital) connector on the video card.

   - Connect the DVI Cable to the DVI port on the back of your LCD Display and the DVI port on the computer.

Downloaded From TV-Manual.com Manuals

2-3 Using the HDMI (digital) output on the graphics card.

- Connect the HDMI IN port on the monitor to the HDMI port on the PC using the HDMI cable.

Note

- When the HDMI cable to the PC, ensure that you select **HDMI** from both the **Source List** and **Edit Name** before selecting **PC** or **DVI** device so that normal PC screen and sound can be outputted.
- Note that sound is only available when connected according to the option 2 that follows.

3 Connect the audio cable for your LCD Display to the audio port on the back of the LCD Display.

Note

- Turn on both your computer and the LCD Display.
- Contact a local SAMSUNG Electronics Service Center to buy optional items.

Connecting to Other devices

AV input devices such as DVD players, VCRs or camcorders as well as your computer can be connected to the LCD Display. For detailed information on connecting AV input devices, refer to the contents under Adjusting Your LCD Display.

The LCD Display 's configuration at the back may vary slightly depending on the LCD Display model.

Connecting TV

Note

You may view television programs on the LCD Display if it is connected to an antenna or CATV cable without installing any separate TV reception hardware or software on your computer.

Downloaded From TV-Manual.com Manuals



1. Connect the CATV cable or TV antenna cable to the "ANT IN" port on the rear side of the LCD Display.

   Using a TV antenna cable (sold separately).

   - *When using an interior antenna terminal:*

     Check the antenna terminal on the wall first and connect the antenna cable.

   - *When using an outdoor antenna:*

     If you are using an outdoor antenna, use a professional for installation if possible.

   - *To connect the RF cable to the antenna input terminal:*

     Keep the copper wire portion of the RF cable straight.

2. Turn on the LCD Display.
3. Select TV using the TV / DTV.
4. Select a desired TV channel.

Connecting COMMON INTERFACE

Note

You can install the CAM anytime whether the TV is ON or OFF.

Purchase the CI CAM module by visiting your nearest dealer or by phone.



1. Insert the CI CARD into the CAM in the direction of the arrow until it fits.

Downloaded From TV-Manual.com Manuals

2. Insert the CAM with the CI CARD installed into the common interface slot.

   (Insert the CAM in the direction of the arrow, right up to the end so that it is parallel with the slot.)

3. Check if you can see a picture on a scrambled signal channel.

Connecting AV Devices



1. Connect the Video and Audio [R-AUDIO-L] port of the DVD, VCR or DTV Set-Top Box to the Video and Audio [R-AUDIO-L] LCD Display.
2. Play the DVD, VCR or Camcorder with a DVD disc or tape inserted.
3. Select **AV** using the SOURCE button on the front of the LCD display or on the remote.

Connecting using a Component Cable



1. Connect the Component to D-sub cable(sold separately) to the product's RGB/COMPONENT IN port and the COMPONENT - PR, Y, PB ports on the Set-Top Box.
2. Connect a set of audio cables between the AV/COMPONENT AUDIO IN [R-AUDIO-L] on the LCD Display and the AUDIO OUT jacks on the Set Top Box.

Note

- Select **Component** using the SOURCE button on the front of the LCD Display or on the remote control.
- Then, start the DVD Player with a DVD disc inserted.
- A component cable is optional.

Downloaded From TV-Manual.com Manuals

- For an explanation of Component video, consult your DVD or external device's user manual.

Connecting to a Camcorder



1. Locate the AV output jacks on the camcorder. They are usually found on the side or back of the camcorder. Connect a set of audio cables between the AUDIO OUTPUT jacks on the camcorder and the AV/COMPONENT AUDIO IN [R-AUDIO-L] on the LCD Display .
2. Connect a video cable between the VIDEO OUTPUT jack on the camcorder and the AV IN [VIDEO] on the LCD Display .
3. Select **AV** for the Camcorder connection using the SOURCE button on the front of the LCD Display or on the remote control.
4. Then, start the Camcorder with a tape inserted.

Note

The audio-video cables shown here are usually included with a Camcorder. (If not, check your local electronics store.) If your camcorder is stereo, you need to connect a set of two cables.

Connecting Using a HDMI Cable



1. Connect input devices such as a Blu-Ray/DVD player to the HDMI IN terminal of the LCD Display using an HDMI cable.

Note

- In HDMI mode, only PCM format audio is supported.

Downloaded From TV-Manual.com Manuals

Connecting Using a DVI to HDMI Cable



1. Connect the DVI output terminal of a digital output device to the HDMI IN terminal of the LCD Display using a DVI to HDMI cable.
2. Connect the red and white jacks of an RCA to stereo (for PC) cable to the same colored audio output terminals of the digital output device, and connect the opposite jack to the DVI / RGB AUDIO IN terminal of the LCD Display.

Connecting Using a DVI Cable



1. Connect between the DVI OUT port on the LCD monitor and the input port on another monitor using a DVI cable.
2. Connect between the AUDIO OUT port on the LCD monitor and the audio input port on another monitor using a stereo cable.
3. Select **DVI** using the SOURCE button on the front of the LCD Display or on the remote control.

Note

- DVI-OUT does not support HDCP.

Downloaded From TV-Manual.com Manuals

Connecting a DTV Set Top (Cable/Satellite) Box



1. Connect the Component to D-sub cable(sold separately) to the product's RGB/COMPONENT IN port and the COMPONENT - PR, Y, PB ports on the Set-Top Box.
2. Connect a set of audio cables between the AV/COMPONENT AUDIO IN [R-AUDIO-L] on the LCD Display and the AUDIO OUT jacks on the Set Top Box.

Note

- Select Component using the SOURCE button on the front of the LCD Display or on the remote control.
- For an explanation of Component video, see your Set Top Box owner's manual.

Connecting to an Audio System



1. Connect a set of audio cables between the AUX L, R jacks on the AUDIO SYSTEM and AUDIO OUT on LCD Display.

Connecting a LAN Cable

Note

- AV input devices such as DVD players, VCRs or camcorders as well as your computer can be connected to the LCD Display. For detailed information on connecting AV input devices, refer to the contents under Adjusting Your LCD Display.
- The LCD Display 's configuration at the back may vary slightly depending on the LCD Display model.

Downloaded From TV-Manual.com Manuals



Connect the LAN cable.

(CXN-2 model only)

Connecting a USB device

- You can connect USB devices such as a mouse or keyboard.

  (CXN-2 model only)



Downloaded From TV-Manual.com Manuals

Using the Software

Monitor Driver

> **Note**
>
> When prompted by the operating system for the monitor driver, insert the CD-ROM included with this monitor. Driver installation is slightly different from one operating system to another. Follow the directions appropriate for the operating system you have.
>
> Prepare a blank disk and download the driver program file at the Internet web site shown here.
> **Internet web site :**
>
> http://www.samsung.com/

Installing the Monitor Driver (Automatic)

1. Insert CD into the CD-ROM drive.
2. Click "Windows".
3. Choose your monitor model in the model list, then click the "OK" button.


SAMSUNG monitor installer
Select the display adapter on which you want to intall the monitor
1. RADEON 9550 : Plug and Play Monitor
Select the monitor which you want to install
Samsung ****
OK
CANCEL

4. If you can see following message window, then click the "Continue Anyway" button. Then click "OK" button (Microsoft® Windows® XP/2000 Operating System).


Hardware Installation
The software you are installing for this hardware:
Samsung ****
has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
Continue Anyway
STOP Installation

Downloaded From TV-Manual.com Manuals

Note

This monitor driver is certified by Microsoft, and installing it will not damage your system.

The certified driver will be posted on Samsung Monitor homepage.

http://www.samsung.com/

Installing the Monitor Driver (Manual)

Microsoft® Windows Vista™, Operating System

1. Insert your Manual CD into your CD-ROM drive.
2. Click (Start) and "Control Panel". Then, double-click on "Appearance and Personalization".

3. Click "Personalization" and then "Display Settings".

4. Click "Advanced Settings...".

5. Click "Properties" in the "Monitor" tab. If the "Properties" button is deactivated, it means the configuration for your monitor is completed. The monitor can be used as is.

Downloaded From TV-Manual.com Manuals

If the message "Windows needs..." is displayed, as shown in the figure below, click "Continue".


Generic PnP Monitor and NVIDIA GeForce 6600 LE (Microsoft Co...
Adapter
Monitor
Troubleshoot
Color Management
Monitor Type
Generic PnP Monitor
Properties
Monitor Settings
Screen refresh rate:
60 Hertz
Hide modes that this monitor cannot display
Clearing this check box allows you to select display modes that this monitor cannot display correctly. This may lead to an unusable display and/or damaged hardware.
OK
Cancel
Apply

Note

This monitor driver is under certifying MS logo, and this installation will not damage your system.

The certified driver will be posted on Samsung Monitor homepage.

6. Click "Update Driver..." in the "Driver" tab.





7. Check the "Browse my computer for driver software" checkbox and click "Let me pick from a list of device drivers on my computer".


How do you want to search for driver software?
Search automatically for updated driver software
Browse my computer for driver software
Locate and install driver software manually.
Cancel

Browse for driver software on your computer
Include subfolders
Browse...
Let me pick from a list of device drivers on my computer
Next
Cancel

8. Click "Have Disk..." and select the folder (for example, D:₩Drive) where the driver setup file is located, and click "OK".

Downloaded From TV-Manual.com Manuals




Install From Disk
Insert the manufacturer's installation disk, and then make sure that the correct drive is selected below.
OK
Cancel
Copy manufacturer's files from:
Browse...

9. Select the model that matches your monitor from the list of monitor models on the screen, and click "Next".



10. Click "Close" → "Close" → "OK" → "OK" on the following screens displayed in sequence.






Generic PnP Monitor and NVIDIA GeForce 6600 LE (Microsoft Co...
Adapter
Monitor
Troubleshoot
Color Management
Monitor Type
Generic PnP Monitor
Properties
Monitor Settings
Screen refresh rate:
60 Hertz
Hide modes that this monitor cannot display
Clearing this check box allows you to select display modes that this monitor cannot display correctly. This may lead to an unusable display and/or damaged hardware.
OK
Cancel
Apply



Downloaded From TV-Manual.com Manuals

Microsoft® Windows® XP Operating System

1. Insert CD into the CD-ROM drive.
2. Click "Start" → "Control Panel", then click the "Appearance and Themes" icon.



3. Click "Display" icon and choose the "Settings" tab then click "Advanced...".





4. Click the "Properties" button on the "Monitor" tab and select "Driver" tab.





5. Click "Update Driver..." and select "Install from a list or..." then click "Next" button.




Hardware Update Wizard
Welcome to the Hardware Update Wizard
This wizard helps you install software for:
Plug and Play Monitor
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel

6. Select "Don't search, I will...", then click "Next" and then click "Have disk".

Downloaded From TV-Manual.com Manuals


Hardware Update Wizard
Please choose your search and installation options.
Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM...)
Include this location in the search:
A:\
Browse
Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
< Back
Next >
Cancel


Hardware Update Wizard
Select the device driver you want to install for this hardware.
Select the manufacturer and model of your hardware device and then click Next. If you have a disk that contains the driver you want to install, click Have Disk.
Show compatible hardware
Model
Plug and Play Monitor
This driver is digitally signed.
Tell me why driver signing is important
Have Disk...
< Back
Next >
Cancel

7. Click the "Browse" button then choose A:(D: ₩Driver) and choose your monitor model in the model list and click the "Next" button.




Hardware Update Wizard
Select the device driver you want to install for this hardware.
Select the manufacturer and model of your hardware device and then click Next. If you have a disk that contains the driver you want to install, click Have Disk.
Model
Samsung ****
This driver is not digitally signed!
Tell me why driver signing is important
Have Disk...
< Back
Next >
Cancel

8. If you can see the following message window, click the "Continue Anyway" button. Then click "OK" button.


Hardware Installation
The software you are installing for this hardware:
Samsung ****
has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
Continue Anyway
STOP Installation

Note

This monitor driver is certified by Microsoft, and this installation will not damage your system.

The certified driver will be posted on Samsung Monitor homepage.

http://www.samsung.com/

9. Click the "Close" button, then click the "OK" button continually.

Downloaded From TV-Manual.com Manuals



10. Monitor driver installation is completed.

Microsoft® Windows® 2000 Operating System

When you can see "Digital Signature Not Found" on your monitor, follow these steps.

1. Choose "OK" button on the "Insert disk" window.
2. Click the "Browse" button on the "File Needed" window.
3. Choose A:(D:₩Driver), then click the "Open" button and then click "OK" button.

How to install

1. Click "Start", "Setting", "Control Panel".
2. Double click the "Display" icon.
3. Select the "Settings" tab and click "Advanced Properties" button.
4. Choose "Monitor".

   Case1 : If the "Properties" button is inactive, it means your monitor is properly configured. Please stop installation

   Case2 : If the "Properties" button is active, click the "Properties" button, then follow the next steps.
5. Click "Driver" and then click on "Update Driver..." then click on the "Next" button.
6. Choose "Display a list of the known drivers for this device so that I can choose a specific driver", then click "Next" and then click "Have disk".
7. Click the "Browse" button, then choose A:(D:₩Driver).
8. Click the "Open" button, then click "OK" button.
9. Choose your monitor model and click the "Next" button, then click "Next" button.
10. Click the "Finish" button , then the "Close" button.

    If you can see the "Digital Signature Not Found" window , then click the "Yes" button. Then click the"Finish" button and the "Close" button.

Microsoft® Windows® Millennium Operating System

1. Click "Start", "Setting", "Control Panel".
2. Double click the "Display" icon.
3. Select the "Settings" tab and click "Advanced Properties" button.

Downloaded From TV-Manual.com Manuals

4. Select the "Monitor" tab.
5. Click the "Change" button in the "Monitor Type" area.
6. Choose "Specify the location of the driver".
7. Choose "Display a list of all the driver in a specific location...", then click "Next" button.
8. Click the "Have Disk" button.
9. Specify A:₩(D:₩driver), then click "OK" button.
10. Select "Show all devices" and choose the monitor that corresponds to the one you connected to your computer and click "OK".
11. Continue choosing "Close" button and "OK" button until you close the Display Properties dialogue box.

Microsoft® Windows® NT Operating System

1. Click "Start", "Settings", "Control Panel", and then double-click "Display" icon.
2. In Display Registration Information window, click Settings Tab and then click "All Display Modes".
3. Select a mode that you wish to use (Resolution, Number of colors and Vertical frequency) and then click "OK".
4. Click "Apply" button if you see the screen working normally after clicking "Test". If the screen is not normal, change to a different mode (lower mode of resolution, colors or frequency).

Note

If there is no Mode at All Display Modes, select the level of resolution and vertical frequency by referring to the Preset Timing Modes in the user guide.

Linux Operating System

To execute X-Window, you need to make the X86Config file, which is a type of system setting file.

1. Press "Enter" at the first and the second screen after executing the X86Config file.
2. The third screen is for setting your mouse.
3. Set a mouse for your computer.
4. The next screen is for selecting a keyboard.
5. Set a Keyboard for your computer.
6. The next screen is for setting your monitor.
7. First of all, set a horizontal frequency for your monitor. (You can enter the frequency directly.)
8. Set a vertical frequency for your monitor. (You can enter the frequency directly.)

Downloaded From TV-Manual.com Manuals

9. Enter the model name of your monitor. This information will not affect the actual execution of X-Window.

10. You have finished setting up your monitor. Execute X-Window after setting other requested hardware.

MDC (Multi-Display Channel)

Installation

1. Insert the installation CD into the CD-ROM drive.

2. Click the MDC installation file.

   Note

   If the popup window to install the software for the main screen is not displayed, proceed with the installation using the MDC executable file on the CD.

3. When the Installation Shield Wizard window appears, click "Next".

4. Select "I agree to the terms of the license agreement" to accept the terms of use.

5. Click "Install".

6. The "Installation Status" window appears.

7. Click "Finish".

8. When the installation is complete, the MDC executable icon appears on your desktop. Double-click the icon to start the program.

MDC execution icon may not appear depending on specification of computer system or monitor. If that happens, press F5 Key.

Installation Problems

The installation of MDC can be affected by such factors as the video card, motherboard and the network environment.

Uninstall

The MDC program can be removed only by using the "Add or Remove Programs" option of the Windows® Control Panel.

Perform the following steps remove MDC.

Downloaded From TV-Manual.com Manuals

Select "Setting/Control Panel" on the "Start" menu and then double-click "Add/Delete a program".

Select MDC from the list and then click the "Add/Delete" button.

■ Using MDC

Downloaded From TV-Manual.com Manuals

Multiple Display Control

MDC System

Introduction



A Multiple Display Control (MDC) is an application allowing various displays to be easily and simultaneously operated on a PC. RS-232C, a standard of serial communication, is used for the communication between a PC and a display. Therefore, a serial cable should be connected between the serial port on a PC and the serial port on a display.

Main Screen

Click Start > Program > Samsung > MDC System to start the program.

Select a set to see the volume of the selected set within the slider.

Downloaded From TV-Manual.com Manuals



1 **Main Icons**
2 **Remocon**
3 **Safety Lock**
4 **Port Selection**
5 **Select Button**
6 **Info Grid**
7 **Display Selection**
8 **Control Tools**

---

1. Use the main icons to switch into each screen.
2. Allows you to enable or disable the remote control signal receiving function of the display unit.
3. Set the Safety Lock function.
   When setting the Lock function, you can only operate power and lock buttons on the remote control and set.
4. The setting for the PC Serial Port can change. The original value is COM1.
5. Click Select all or Clear to select or clear all displays.
6. Use Grid to view brief information on selected display.
7. Select a display from Display Selection.
8. Use Control Tools to control displays.

<Note> The remote control Enable/Disable function operates whether or not the power is On/Off, and this applies to all displays connected to the MDC. However, regardless of the status at the time the MDC is shut down, the remote control signal receiving function of all displays is initialized to Enable when the MDC is closed.

Port Selection

Downloaded From TV-Manual.com Manuals



1. The Multiple Display Control is originally set to COM1.
2. If any port other than COM1 is used, COM1 through COM4 can be selected in the Port Selection Menu.
3. If the exact port name that is connected to the LCD Display using a serial cable is not selected, communication will be unavailable.
4. The selected port is stored in the program and used for the next program as well.

Power Control

1. Click Power Control of the main icons and the Power Control screen appears.

Downloaded From TV-Manual.com Manuals



✱ Info Grid shows some basic information necessary to Power Control.

1) (Power Status)
2) Input
3) Image Size
4) On Timer
5) Off Timer

2. Use the Select All button or Check Box to choose a display to control.

Downloaded From TV-Manual.com Manuals



✱ ☑ Power Control allows controlling some of the functions of the selected display.

1) Power On/Off
   - Turns the power of the selected display On/Off.

2) Volume
   - Controls the volume level of the selected display.
     It receives the volume value of the selected display from the sets and displays it in the slider.
     (When you cancel the selection or choose Select All, the value returns to the default value 10)

3) (Mute On/Off)
   - Turns on/off the Mute function of the selected display.
     When selecting one set at a time, turn on the Mute function for the selected set.
     The Mute function is disabled automatically when you adjust the volume level.
     (The values return to the default settings when you undo the selections or choose "Select All".)

✱ **The Power Control feature is available for all displays.**

✱ **The Volume Control and Mute features are available only for the displays whose power status is ON.**

Input Source

1. Click Input Source of the main icons and the Input Source control screen appears.
   Click Select All or use Check Box to select a display to control.

• TV Mode

Downloaded From TV-Manual.com Manuals



- PC Mode

Downloaded From TV-Manual.com Manuals



✱ Info Grid shows some basic information necessary to Input Source Control.

1) PC
   - Changes the Input Source of the selected display to PC.
2) BNC
   - Changes the Input Source of the selected display to BNC.
3) DVI
   - Changes the Input Source of the selected display to DVI.
4) TV
   - Changes the Input Source of the selected display to TV.
5) DTV
   - Changes the Input Source of the selected display to DTV.
6) AV
   - Changes the Input Source of the selected display to AV.
7) S-Video
   - Changes the Input Source of the selected display to S-Video.
8) Component
   - Changes the Input Source of the selected display to Component.
9) MagicInfo
   - The Input source of MagicInfo works only on MagicInfo model.
10) HDMI
   - Changes the Input Source of the selected display to HDMI.
11) Channel
   - Channel arrow appears when the Input Source is TV.

✱ **TV Source can be selected only in products with TV and controlling channels is allowed only when Input Source is TV.**

Downloaded From TV-Manual.com Manuals

The Input Source Control feature is available only for the displays whose power status is ON.

Image Size

PC, BNC, DVI

1. Click Image Size of the main icons and the Image Size control screen appears.



Info Grid shows some basic information necessary to Image Size Control.

1) (Power Status)
   - Shows the power status of the current display.
2) Image Size
   - Shows the current Image Size of the display in use.
3) Input
   - Info Grid displays only the displays whose Input Source is PC, BNC, DVI.
4) PC Source
   - When you click Image Size, the PC Source tab first appear.
   - The Image Size Control button controls Image Size available for PC, BNC, DVI.
5) Video Source
   - Click the Video Source tab to control Image Size for respective Input Source.

The Input source of MagicInfo works only on MagicInfo model.

The Input source of TV works only on TV model.

Image Size Control is available only for the displays for which power status is ON.

Downloaded From TV-Manual.com Manuals

Image Size

TV, AV, S-Video, Component, DVI(HDCP), HDMI, DTV

1. Click Image Size of the main icons and the Image Size control screen appears.



✱ Info Grid shows some basic information necessary to Image Size Control.

1) Click the Video Source tab to adjust Image Size for TV, AV, S-Video, Component, DVI(HDCP), HDMI, DTV. Click Select All or use Check Box to select a display to control.
2) Info Grid displays only the display having TV, AV, S-Video, Component or DVI(HDCP) as input source.
3) Switch Image Size of the selected display randomly.

   Note: Auto Wide, Zoom1 and Zoom2 are not available for selection when the input signal type for Component and DVI (HDCP) is 720p or 1080i.
   (The Auto Wide mode is available only for TV, AV, and S-Video.)
4) The screen modes can only be adjusted when a TV (PAL only) is connected and the Image Size item is set to Auto Wide.

✱ **The Input source of MagicInfo works only on MagicInfo model.**

✱ **The Input source of TV works only on TV model.**

✱ **The Image Size Control feature is available only for the displays whose power status is ON.**

Time

Downloaded From TV-Manual.com Manuals

1. Click Time of the main icons and the Time Control screen appears.



✱ Info Grid shows some basic information necessary to Time Control.

1) Current Time
   - Set the current time for the selected display (PC Time).
   - To change the current time, first change the PC Time.
2) On Time Setup
   - Set the Hour, Minute, AM/PM of On Time Setup, Status, Source, Volume of the selected display.
3) Off Time Setup
   - Set the Hour, Minute, and AM/PM, Status for Off Time Setup of the selected display.
4) Shows the On Time settings.
5) Shows the Off Time settings.

✱ **The Input source of MagicInfo works only on MagicInfo model.**

✱ **The Input source of TV works only on TV model.**

✱ **Time Control is available only for the displays for which the power status is ON.**

✱ **At On Time Setup, TV Source functions only for TV Model.**

✱ **At On Time Setup, MagicInfo Source functions only for MagicInfo Model.**

PIP

Downloaded From TV-Manual.com Manuals

PIP Size

1. Click PIP of the main icons and the PIP control screen appears.
   Click Select All or use Check Box to select a display to control.



✱ Info Grid shows some basic information necessary to PIP Size Control.

1) PIP Size
   - Shows the current PIP Size of the display in use.
2) OFF
   - Turns off the PIP of the selected display.
3) Large
   - Turns on the PIP of the selected display and changes the size to Large.
4) Small
   - Turns on the PIP of the selected display and changes the size to Small.
5) Double 1
   - Turns on the PIP of the selected display and changes the size to Double 1.
6) Double 2
   - Turns on the PIP of the selected display and changes the size to Double 2.
7) Double 3 (Picture By Picture)
   - Turns on the PBP of the selected display and changes the size to Double 3.

✱ **The Input source of MagicInfo works only on MagicInfo model.**

✱ **The Input source of TV works only on TV model.**

✱ **PIP Size can be controlled with turning on the LCD Display power.**

Downloaded From TV-Manual.com Manuals

PIP

PIP Source

1. Click PIP of the main icons and the PIP control screen appears.



✱ Info Grid shows some basic information necessary to PIP Source Control.

1) PIP Source
   - PIP Source can be controlled with turning on the LCD Display power.
2) PC
   - Changes the source of the PIP of the selected display to PC.
3) BNC
   - Changes the source of the PIP of the selected display to BNC.
4) DVI
   - Changes the source of the PIP of the selected display to DVI.
5) AV
   - Changes the source of the PIP of the selected display to AV.
6) S-Video
   - Changes the source of the PIP of the selected display to S-Video.
7) Component
   - Changes the source of the PIP of the selected display to Component.
8) HDMI
   - Changes the source of the PIP of the selected display to HDMI.

Note: Some of the PIP Sources may not be available for selection, depending on the input source type of the Main Screen.

✱ **The Input source of MagicInfo works only on MagicInfo model.**

✱ **The PIP Control feature is available only for the displays whose power status is ON and the PIP function is set to ON.**

Downloaded From TV-Manual.com Manuals

Settings

Picture

1. Click Settings of the main icons and the Settings Control screen appears.



✱ Info Grid shows some basic information necessary to Settings Control.
When each function is selected, the set value of the selected function is displayed in the slide.When selected, each function fetches the value for the set and displays it on the slide bar. When "Select All" is chosen, the default value is displayed. Changing a value in this screen will automatically change the mode to "CUSTOM."

1) Picture
   - Available only for TV, AV, S-Video, Component, HDMI, DTV.
2) Contrast
   - Adjusts Contrast of the selected display.
3) Brightness
   - Adjusts Brightness of the selected display.
4) Sharpness
   - Adjusts Sharpness of the selected display.
5) Color
   - Adjusts Color of the selected display.
6) Tint
   - Adjusts Tint of the selected display.
   - Available only for NT.
7) Color Tone

Downloaded From TV-Manual.com Manuals

- Adjusts the Color Tone for the selected display.

8) Color Temp
   - Adjusts the Color Temp for the selected display.

9) Brightness Sensor
   - Adjusts the Brightness Sensor for the selected display.

10) Dynamic Contrast
   - Adjusts the Dynamic Contrast for the selected display.

* **The Input source of MagicInfo works only on MagicInfo model.**
* **Color Temp is only enabled if the Color Tone is set to Off.**
* **The Input source of TV works only on TV model.**
* **This feature is available only for the displays whose power status is ON and if no selection is made, the factory default is displayed.**

Settings

Picture PC

1. Click Settings of the main icons and the Settings Control screen appears.

* Info Grid shows some basic information necessary to Settings Control. When each function is selected, the set value of the selected function is displayed in the slide. When selected, each function fetches the value for the set and displays it on the slide bar. When "Select All" is chosen, the default value is displayed. Changing a value in this screen will automatically change the mode to "CUSTOM."

1) Picture PC
   - Available only for PC, BNC, DVI.

Downloaded From TV-Manual.com Manuals

2) Contrast
   - Adjusts Contrast of the selected display.
3) Brightness
   - Adjusts Brightness for the selected display.
4) Red
   - Adjusts red Color of the selected display.
   - Available only for NT.
5) Green
   - Adjusts green Color of the selected display.
   - Available only for NT.
6) Blue
   - Adjusts blue Color of the selected display.
   - Available only for NT.
7) Color Tone
   - Adjusts the Color Tone for the selected display.
8) Color Temp
   - Adjusts the Color Temp for the selected display.
9) Brightness Sensor
   - Adjusts the Brightness Sensor for the selected display.
10) Dynamic Contrast
   - Adjusts the Dynamic Contrast for the selected display.

* **The Input source of MagicInfo works only on MagicInfo model.**
* **The Input source of TV works only on TV model.**
* **Color Temp is only enabled if the Color Tone is set to Off.**
* **This feature is available only for the displays whose power status is ON and if no selection is made, the factory default is displayed.**

Settings

Audio

1. Click Settings of the main icons and the Settings Control screen appears.

Downloaded From TV-Manual.com Manuals



✱ Info Grid shows some basic information necessary to Settings Control. When each function is selected, the set value of the selected function is displayed in the slide. When selected, each function fetches the value for the set and displays it on the slide bar. When "Select All" is chosen, the default value is displayed. Changing a value in this screen will automatically change the mode to "CUSTOM."

1) Audio
   - Controls audio settings for all input sources.
2) Bass
   - Adjusts Bass of the selected display.
3) Treble
   - Adjusts Treble of the selected display.
4) Balance
   - Adjusts Balance of the selected display.
5) SRS TS XT
   - SRS TS XT Sound ON/OFF of the selected display.
6) Sound Select
   - Select either Main or Sub when PIP is On.

✱ **The Input source of MagicInfo works only on MagicInfo model.**

✱ **The Input source of TV works only on TV model.**

✱ **This feature is available only for the displays whose power status is ON and if no selection is made, the factory default is displayed.**

Settings

Downloaded From TV-Manual.com Manuals

Image Lock

1. Click Settings of the main icons and the Settings Control screen appears.



✱ Info Grid shows some basic information necessary to Settings Control.

1) Image Lock
   - Available only for PC, BNC.
2) Coarse
   - Adjusts Coarse of the selected display.
3) Fine
   - Adjusts Fine of the selected display.
4) Position
   - Adjusts Position of the selected display.
5) Auto Adjustment
   - Self-Adjust to the incoming PC signal.

✱ **The Input source of MagicInfo works only on MagicInfo model.**

✱ **The Input source of TV works only on TV model.**

✱ **Settings Control is available only for the displays for which the power status is ON.**

Maintenance

Lamp Control

1. Click on the "Maintenance" icon in the Main Icon column to display the Maintenance screen.

Downloaded From TV-Manual.com Manuals



✱ An "Info Grid" showing several basic data items appears.

1) Maintenance
   - Allows the Maintenance Control function for all input sources.

2) Auto Lamp Control
   - Automatically adjusts the backlight of the selected display at a specified time.
     The Manual Lamp Control automatically turns off if you adjust using the Auto Lamp Control.

3) Manual Lamp Control
   - Allows you to adjust the backlight of the selected display regardless of the time.
     The Auto Lamp Control automatically turns off if you adjust using the Manual Lamp Control.

✱ **The Maintenance Control feature is available only for the displays whose power status is ON.**

✱ **The Input source of MagicInfo works only on MagicInfo model.**

✱ **The Input source of TV works only on TV model.**

Maintenance

Scroll

1. Click on the "Maintenance" icon in the Main Icon column to display the Maintenance screen.

Downloaded From TV-Manual.com Manuals



1) Scroll
   - This function is used to remove the afterimages that occur when a still screen is displayed on the selected display
     for a long time.

2) Pixel Shift
   - This allows the screen to be moved finely at the specified time interval.

3) Safety Screen
   - The Safety Screen function is used to prevent afterimages from occurring when a still screen is displayed on the monitor for a long time. The Interval item is used to set the repetition cycle in hour units and the Time item is used to set the time when the Safety Screen function must be performed.
     The Type item can be set to Scroll, Pixel, Bar, Eraser, All White, or Pattern.

4) Safety Screen2
   - This function is used to prevent afterimages from occurring. There are five (5) types that you can select and control with this function.

* **For the Scroll type, the Time item can be set to 1, 2, 3, 4 or 5. For the Bar and Eraser types, it can be set to 10, 20, 30, 40 or 50. For the All White and Pattern type, it can be set to 1, 5, 10, 20 or 30.**
* **The Input source of MagicInfo works only on MagicInfo model.**
* **The Input source of TV works only on TV model.**
* **The Maintenance Control feature is available only for the displays whose power status is ON.**

Maintenance

Video Wall

Downloaded From TV-Manual.com Manuals

1. Click on the "Maintenance" icon in the Main Icon column to display the Maintenance screen.



1) Video Wall
   - A Video Wall is a set of video screens that are connected together, so that each screen shows a part of the whole picture or so that the same picture is repeated on each screen.

2) Video Wall (Screen divider)
   - The screen can be divided into.
     You can select a number of screens with a different layout when dividing.
     - Select a mode from Screen divider.
     - Select a display from Display Selection.
     - The place will be set up by pressing a number in the selected mode.
     - The MDC program supplied by Samsung supports up to 5x5 LCD Displayes.

3) On / Off
   - Turns on/off the Video Wall function of the selected display.

4) Format
   - The format can be selected to see a divided screen.

   - Full



   - Natural

Downloaded From TV-Manual.com Manuals



* **You may not operate this function in MagicInfo.**
* **The Input source of TV works only on TV model.**
* **The Maintenance Control function is available only for the displays where the power status is ON.**

Troubleshooting

1. The display you wish to control does not appear on the Power Control Info Grid
   - Check the connection of RS232C. (Check if it is properly connected to the Com1 port)
   - Check the displays to see if any of the other displays connected have the same ID. If more than one displays have the same ID, those displays are not properly detected by the program due to data conflict.
   - Check if the Display Set ID is a number between 0 and **25**. (Adjust using the Display menu)

   Note : A Display Set ID must be a value between 0 and **25** .

2. The display you wish to control does not appear on the other Control Info Grids
   - Check to see if the display power is ON. (You can check this in Power Control Info Grid)
   - Check if you can change the input source of the display.

3. The dialogue box appears repeatedly.
   - Check to see if the display you wish to control is selected. ☑

4. Both On Timer and Off Timer have been set but different time is showing.
   - Apply current time to synchronize the display clocks.

5. The remote may not function properly when you turn off the remote Function, disconnect the RS-232C cable, or exit the program in an Irregular manner. Rerun the program and turn the remote function again to Restore normal functions.

   <Note> This program may malfunction due to problems in communication circuits or interference from electronic appliances nearby.

Settings Value Display In Multiple Display Mode

* When there are more than one displays connected, the settings values are displayed as follows.

1. No selection: Displays the Factory Default Value.

Downloaded From TV-Manual.com Manuals

2. Selected one display: Fetches and displays the settings value for the selected display.
3. Selected one display (ID1) and add another display (ID3): The program, which was displaying the settings value of ID 1, fetches and displays the value of ID3.
4. Selected all sets using Select All: Returns to the Factory Default Value.

Copyright© 2003-2009 Samsung Electronics Co. Ltd. All rights reserved.

Downloaded From TV-Manual.com Manuals

Adjusting the LCD Display

Input

Available Modes

- P PC / DVI
- A AV
- C Component
- H HDMI
- M MagicInfo
- T TV

Note

MagicInfo supports the CXN-2 model only.

Source List P A C H M T

MENU → ENTER → **[Input]** → ENTER → **[Source List]**

→ ▲ , ▼ → ENTER

Use to select **PC**, **DVI** or other external input sources connected to the LCD Display. Use to select the screen of your choice.

1. **PC**
2. **DVI**
3. **AV**
4. **Component**
5. **HDMI**
6. **MagicInfo**
7. **TV**

Note

- The direct button on the remote control is the 'SOURCE' button.

Downloaded From TV-Manual.com Manuals

PIP

Note

Available Modes: **PIP ON**

When external AV devices such as VCRs or DVDs are connected to the LCD Display , **PIP** allows you to watch video from those devices in a small window super-imposed on the PC Video signal. (**Off**/**On**)

MENU → ENTER → [**Input**] → ▼ → ENTER → [PIP]

Note

- If you select , , in **Size**, **Position** and **Transparency** will not be activated.

PIP

MENU → ENTER → [**Input**] → ▼ → ENTER → [PIP] → ENTER → [PIP]



→ ▲ , ▼ → ENTER

Turns the **PIP** Screen **Off**/**On**.

- **Off**
- **On**

Source

MENU → ENTER → [**Input**] → ▼ →ENTER → [PIP] → ▼ →ENTER → [Source]



→ ▲ , ▼ → ENTER

Selects the input source for the PIP.

- **PC** : **DVI** / **AV** / **HDMI** / **TV**
- **DVI** : **PC** / TV
- **Component** : **TV**

Downloaded From TV-Manual.com Manuals

- **AV : PC** / TV
- **HDMI : PC** / **TV**
- **TV : PC** / **DVI** / **AV** / **Component** / **HDMI**

Note

The direct button on the remote control is the 'SOURCE' button.

Swap

MENU → ENTER → **[Input]** → ▼ →ENTER → [PIP] → ▼→ ▼ →ENTER → [Swap]



Swaps the contents of the PIP and main image.

The image in the PIP window will appear on the main screen, and the main screen image will appear in the PIP window.

Size

MENU → ENTER → **[Input]** → ▼ →ENTER → [PIP] → ▼ → ▼ → ▼ → ENTER → [Size]

→ ▲ , ▼ → ENTER

Changes the Size of the PIP window.

Position

MENU → ENTER → **[Input]** → ▼ →ENTER → [PIP] → ▼ → ▼ → ▼ → ▼ → ENTER → [Position]

Downloaded From TV-Manual.com Manuals

→ ▲ , ▼ → ENTER

Changes the Position of the PIP window.

Transparency

MENU → ENTER → [Input] → ▼ → ENTER → [PIP] → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ENTER → [Transparency]



→ ▲ , ▼ → ENTER

Adjusts the Transparency of PIP windows.

- **High**
- **Medium**
- **Low**
- **Opaque**

Note

- **PIP** turns off when the LCD Display is switched to an external source.
- For **PC** and **DVI**, this is deactivated if the cable is disconnected.

Edit Name

MENU → ENTER → [Input] → ENTER → ▼ → ▼ → [Edit Name]



→ ▲ , ▼ → ENTER

Name the input device connected to the input jacks to make your input source selection easier.

VCR / DVD / Cable STB / HD STB / Satellite STB / AV Receiver / DVD Receiver / Game / Camcorder / DVD Combo / DHR / PC / HDMI / Component / AV / DVI

Note

- When connecting a PC to the HDMI or DVI terminal, set **Edit Name** to **PC**. In other cases, set **Edit Name** to **AV**. However, since 640x480, 720P (1280x720), and 1080p

Downloaded From TV-Manual.com Manuals

(1920x1080) are common signals for **AV** and **PC**, make sure to set the **Edit Name** in accordance with the input signal.

- The **Picture** menu changes depending on the input signal and **Edit Name**.

Picture [PC / DVI / MagicInfo Mode]

Available Modes

- P PC / DVI
- A AV
- C Component
- H HDMI
- M MagicInfo
- T TV

Note

MagicInfo supports the CXN-2 model only.

MagicBright PM

MENU → ▼ → ENTER → **[Picture]** → ENTER → **[MagicBright]**

→ ▲ , ▼ → ENTER

MagicBright is a feature providing the optimum viewing environment depending on the contents of the image you are watching. Currently four different modes are available: **Entertain**, **Internet**, **Text** and **Custom**. Each mode has its own pre-configured brightness value.

(Not available in **Dynamic Contrast** mode of **On**.)

1. **Entertain**

   High brightness

   For watching motion pictures such as from a DVD or VCR.

2. **Internet**

   Medium brightness

   For working with a mixture of images such as texts and graphics.

Downloaded From TV-Manual.com Manuals

3. **Text**

   Normal brightness

   For documents or works involving heavy text.

4. **Custom**

   Although the values are carefully chosen by our engineers, the pre-configured values may not be comfortable to your eyes depending on your taste.

   If this is the case, adjust the brightness and contrast by using the OSD menu.

Custom PM

By using the on-screen menus, the contrast and brightness can be changed to your personal preference.

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]**

(Not available in **Dynamic Contrast** mode of **On**.)

Note

By adjusting the picture using the **Custom** function, **MagicBright** will change to **Custom** mode.

Contrast

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]**→ ENTER→ **[Contrast]**

→ ◀, ▶ → ENTER

Adjusts the Contrast.

Brightness

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]** → ▼ → ENTER → **[Brightness]**

→ ◀, ▶ → ENTER

Adjusts the Brightness.

Sharpness

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]** → ▼ → ▼ → ENTER → **[Sharpness]**

→ ◀, ▶ → ENTER

Adjusts the Sharpness.

Downloaded From TV-Manual.com Manuals

Color Tone PM

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ →ENTER → [Color Tone]

→ ▲ , ▼ → ENTER

The color tones can be changed.

(Not available in **Dynamic Contrast** mode of **On**.)

1. **Off**
2. **Cool**
3. **Normal**
4. **Warm**
5. **Custom**

Note

If you set the **Color Tone** to **Cool**, **Normal**, **Warm**, or **Custom**, the **Color Temp** function is disabled.

If you set the **Color Tone** to **Off**, the **Color Control** function is disabled

Color Control PM

Adjusts individual Red, Green, Blue color balance.

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ →▼→ ENTER → [Color Control]

(Not available in **Dynamic Contrast** mode of **On**.)

Note

If you adjust the picture by using the **Color Control** function, **Color Tone** will turn to the **Custom** mode.

Red

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ →▼ → ENTER → [Color Control]→ ENTER → [Red]

→ ◄, ► → ENTER

Downloaded From TV-Manual.com Manuals

Green

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ →▼ → ENTER → **[Color Control]**→ ▼ → ENTER → **[Green]**

→ ◀, ▶ → ENTER

Blue

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ →▼ → ENTER → **[Color Control]**→ ▼ → ▼ → ENTER → **[Blue]**

→ ◀, ▶ → ENTER

Color Temp PM

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ →▼ → ENTER → **[Color Temp.]**

→ ◀, ▶ → ENTER

Color Temp is a measure of the 'warmth' of the image colors.

(Not available when Dynamic Contrast is set to On.)

Note

This function is only enabled if the **Color Tone** is set to **Off**.

Image Lock P

Image Lock is used to fine-tune and get the best image by removing noise that creates unstable images with jitters and shakiness. If satisfactory results are not obtained using the Fine adjustment, use the Coarse adjustment and then use Fine again.

(Available in **PC** mode only)

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ →▼ →▼ → ENTER → **[Image Lock]**

Coarse

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ →▼ →▼ → ENTER → **[Image Lock]** → ENTER →**[Coarse]**

→ ◀, ▶ → ENTER

Removes noise such as vertical stripes. Coarse adjustment may move the screen image area. You may relocate it to the center using the horizontal control menu.

Downloaded From TV-Manual.com Manuals

Fine

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ →▼ →▼ → ENTER → **[Image Lock]**→ ▼ → ENTER → **[Fine]**

→ ◄, ► → ENTER

Removes noise such as horizontal stripes. If the noise persists even after Fine tuning, repeat it after adjusting the frequency (clock speed).

Position

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ →▼ →▼ → ENTER → **[Image Lock]**→ ▼ → ▼ → ENTER → [Position]



→ ◄, ►, ▲, ▼ → ENTER

Adjusts the screen location horizontally.

Auto Adjustment P

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼ → ENTER → **[Auto Adjustment]**



The values of **Fine**, **Coarse**, **Position** are adjusted automatically. By changing the resolution in the control panel, the auto function is performed.

(Available in **PC** mode only)

Signal Balance P

This is used to make up for the weak RGB signal transmitted by a long signal cable.

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼ →▼ → ENTER → **[Signal Balance]**

(Available in **PC** mode only)

Signal Balance

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼ →▼ → ENTER → **[Signal Balance]** → ENTER → **[Signal Balance]**

Downloaded From TV-Manual.com Manuals



→ ▲ , ▼ → ENTER

Selects either **On** or **Off** with the signal control.

Signal Control

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[Signal Balance]** → ENTER → ▼ → **[Signal Control]**

1. **R-Gain**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[Signal Balance]** → ENTER → ▼ → **[Signal Control]** → ENTER → **[R-Gain]**

   → ◀, ▶ → ENTER

2. **G-Gain**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[Signal Balance]** → ENTER → ▼→ **[Signal Control]** → ▼ → ENTER→ **[G-Gain]**

   → ◀, ▶ → ENTER

3. **B-Gain**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[Signal Balance]**→ ENTER → ▼→ **[Signal Control]** → ▼ → ▼ → ENTER→ **[B-Gain]**

   → ◀, ▶ → ENTER

4. **R-Offset**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[Signal Balance]**→ ENTER → ▼→ **[Signal Control]** → ▼→ ▼ → ▼ → ENTER→ **[R-Offset]**

   → ◀, ▶ → ENTER

5. **G-Offset**

Downloaded From TV-Manual.com Manuals

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[Signal Balance]**→ ENTER → ▼→ **[Signal Control]** → ▼ → ▼ → ▼ → ▼ → ENTER→ **[G-Offset]**

→ ◀, ▶ → ENTER

6. **B-Offset**

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[Signal Balance]**→ ENTER → ▼→ **[Signal Control]** → ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[B-Offset]**

→ ◀, ▶ → ENTER

Size

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ENTER → [Size]

→ ▲ , ▼ → ENTER

The **Size** can be switched.

1. **16:9**
2. **4:3**

HDMI Black Level

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼ →▼ →▼ → ENTER → **[HDMI Black Level]**

→ ▲ , ▼ → ENTER

When watching with a DVD or set-top box connecting to the product via HDMI, image quality deterioration (black level, lower-quality contrast, lighter color tone, etc.) may occur depending on the connected external device.

Downloaded From TV-Manual.com Manuals

1. Normal
2. Low

Note

For Timing which can be used for both the PC and the DTV in **DVI**, **HDMI** mode, **HDMI Black Level** will be activated.

PIP Picture

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼ → ENTER → [PIP Picture]

→ ▲ , ▼ → ENTER

Adjusts the PIP Screen Settings.

Note

- Available Modes: **PIP ON**

1. **Contrast**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ENTER → [PIP Picture] → ENTER→ **[Contrast]**

   → ◀, ▶ → ENTER

   Adjusts the Contrast of the PIP window on the screen.

2. **Brightness**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ENTER → [PIP Picture] → ENTER → ▼→ **[Brightness]**

   → ◀, ▶ → ENTER

   Adjusts the Brightness of the PIP window on the screen.

3. **Sharpness**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ENTER → [PIP Picture] → ENTER → ▼→ ▼→ **[Sharpness]**

   → ◀, ▶ → ENTER

   Adjusts the difference between the lightest and darkest areas of the PIP window.

   Adjusts the **Sharpness** of the PIP window on the screen.

4. **Color**

Downloaded From TV-Manual.com Manuals

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ENTER → [PIP Picture] → ENTER → ▼→ ▼→ ▼→ [Color]

→ ◄, ► → ENTER

Adjusts the Color of the PIP window on the screen.

Note

- Enabled only when the PIP input is selected in **AV**, **HDMI**, **Component** or **TV mode**.

5. **Tint**

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ENTER → [PIP Picture] → ENTER → ▼→ ▼→ ▼→ ▼→ [Tint]

→ ◄, ► → ENTER

Adds a natural tone to the PIP window.

Note

- Enabled only when the PIP input is selected in **AV**, **HDMI**, **Component** or **TV mode**. Operates only if the video signal is NTSC.

Dynamic Contrast PM

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ▼→ ENTER → [Dynamic Contrast]



→ ▲ , ▼ → ENTER

Dynamic Contrast automatically detects the distribution of the visual signal and adjusts to create an optimum contrast.

1. **Off**
2. **On**

Lamp Control PACHM

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ▼→ ▼→ ENTER → [Lamp Control]

Downloaded From TV-Manual.com Manuals

→ ◀, ▶ → ENTER

Adjusts the inverter lamp in order to reduce energy consumption.

Note

This function does not operate when **Dynamic Contrast** is set to **On** in **PC**, **DVI**, **AV**, **Component**, **HDMI**,MagicInfo ,**TV**, modes.

Brightness Sensor PM

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ▼→ ▼→ ▼→ ▼→ ▼→ ▼→ ENTER → **[Brightness Sensor]**



→ ▲ , ▼ → ENTER

Brightness Sensor automatically detects distribution of the inputted visual signal and adjusts to create optimum brightness.

1. **Off**
2. **On**

Picture [AV / HDMI / TV / Component Mode]

Available Modes

- P **PC / DVI**
- A **AV**
- C **Component**
- H **HDMI**
- M **MagicInfo**
- T **TV**

Mode AHCT

MENU → ▼ → ENTER → **[Picture]** → ENTER → **[Mode]**



→ ▲ , ▼ → ENTER

Downloaded From TV-Manual.com Manuals

The LCD Display has four automatic picture settings ("**Dynamic**", "**Standard**", "**Movie**" and "**Custom**") that are preset at the factory.

Dynamic, **Standard**, **Movie**, or **Custom** can be activated.

(Not available when Dynamic Contrast is set to On.)

1. **Dynamic**
2. **Standard**
3. **Movie**
4. **Custom**

Custom

By using the on-screen menus, the contrast and brightness can be changed to your personal preference.

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]**

(Not available when **Dynamic Contrast** mode is set to **On**.)

Contrast

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]** → ENTER→ **[Contrast]**

→ ◀, ▶ → ENTER

Adjusts the Contrast.

Brightness

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]** → ▼ → ENTER → **[Brightness]**

→ ◀, ▶ → ENTER

Adjusts the Brightness.

Sharpness

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]** → ▼ → ▼ → ENTER → **[Sharpness]**

→ ◀, ▶ → ENTER

Adjusts the picture Sharpness.

Color

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]** → ▼ → ▼ → ▼ → ENTER → **[Color]**

Downloaded From TV-Manual.com Manuals

→ ◀, ▶ → ENTER

Adjusts the picture Color.

Tint

MENU → ▼ → ENTER → **[Picture]** → ▼ → ENTER → **[Custom]** → ▼ → ▼ → ▼→ ▼→ ENTER → **[Tint]**

→ ◀, ▶ → ENTER

Adds a natural tone to the display.

Color Tone AHCT

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ENTER → **[Color Tone]**

→ ▲ , ▼ → ENTER

The color tones can be changed. The individual Color components are also user adjustable.

(Not available when **Dynamic Contrast** is set to **On**.)

1. **Off**
2. **Cool2**
3. **Cool1**
4. **Normal**
5. **Warm1**
6. **Warm2**

Note

If you set the **Color Tone** to **Cool2**, **Cool1**, **Normal**, **Warm1**, or **Warm2**, the **Color Temp** function is disabled.

Color Temp AHCT

MENU → ▼ → ENTER → **[Picture]** → ▼ →▼ →▼ → ENTER → **[Color Temp.]**

Downloaded From TV-Manual.com Manuals

→ ◀, ▶ → ENTER

Color temp is a measure of the 'warmth' of the image colors.

(Not available when **Dynamic Contrast** is set to **On**.)

Note

This function is only enabled if the **Color Tone** is set to **Off**.

Size AHC

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ → ENTER → [Size]

→ ▲ , ▼ → ENTER

The **Size** can be switched.

1. **16:9**: Sets the picture to 16:9 wide mode.
2. **Zoom 1**: Magnifies the size of the picture on the screen.
3. **Zoom 2**: Magnifies the size of the picture more than **Zoom 1**.
4. **4:3**: Sets the picture to 4:3 normal mode.
5. **Screen Fit**: Displays the input scenes as they are without any cutoff when HDMI 720p, 1080i, 1080p signals are input.

(Not available when **Dynamic Contrast** is set to **On**.)

Note

Certain external devices may feed the display an out of spec signal that may cause cutoff even when using the **Screen Fit** feature.

Zoom 1, **Zoom 2** are unavailable in **HDMI** mode.

Note

The **Position** and **Reset** functions are available in Zoom 1 and Zoom 2 modes.

Digital NR (Digital Noise Reduction) AHCT

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼ → ENTER → **[Digital NR]**

Downloaded From TV-Manual.com Manuals

→ ▲ , ▼ → ENTER

Turns the Digital Noise Reduction feature **Off**/**On**. The Digital Noise Reduction feature allows you to enjoy clearer and crisper images.

1. **Off**
2. **On**

Note

Digital NR function is not available for all resolutions.

HDMI Black Level H

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼ →▼ → ENTER → **[HDMI Black Level]**

→ ▲ , ▼ → ENTER

When a DVD or set-top box is connected to your **TV** via **DVI**, **HDMI**, it may cause a degradation in the screen quality, such as an increase in the black level, a low contrast, or discoloration, etc., depending on the external device connected.In this case, adjust the screen quality of your TV by configuring the **HDMI black level**.

1. **Normal**
2. **Low**

Note

For Timing which can be used for both the PC and the DTV in **DVI**, **HDMI** mode, **HDMI Black Level** will be activated.

Film Mode AC

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ENTER → **[Film Mode]**

Downloaded From TV-Manual.com Manuals



→ ▲ , ▼ → ENTER

The **Film Mode** feature offers you a theater-quality viewing experience.

(In **HDMI** mode, this function is available when the input signal is interlaced scan; it is not available in progressive scan.)

1. **Off**
2. **On**

PIP Picture A H C T

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ENTER → **[PIP Picture]**

→ ▲ , ▼ → ENTER

Adjusts the PIP Screen Settings.

Note

Available Modes: **PIP ON**

1. **Contrast**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ENTER → **[PIP Picture]**→ ENTER→ **[Contrast]**

   → ◀, ▶ → ENTER

   Adjusts the Contrast of the PIP window on the screen.

2. **Brightness**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ▼ → ENTER → **[PIP Picture]**→ ▼→ ENTER→ **[Brightness]**

   → ◀, ▶ → ENTER

   Adjusts the Brightness of the PIP window on the screen.

3. **Sharpness**

   MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → **[PIP Picture]** → ENTER → ▼→ ▼→ **[Sharpness]**

Downloaded From TV-Manual.com Manuals

→ ◄, ► → ENTER

Adjusts the difference between the lightest and darkest areas of the PIP window.

Adjusts the **Sharpness** of the PIP window on the screen.

4. **Color**

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → [PIP Picture] → ENTER → ▼→ ▼→ ▼→ **[Color]**

→ ◄, ► → ENTER

Adjusts the Color of the PIP window on the screen.

Note

- Enabled only when the PIP input is selected in **AV**, **HDMI**, **Component** or **TV** mode.

5. **Tint**

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼→ ▼→ ENTER → [PIP Picture] → ENTER → ▼→ ▼→ ▼→ ▼→ **[Tint]**

→ ◄, ► → ENTER

Adds a natural tone to the PIP window.

Note

- Enabled only when the PIP input is selected in **AV**, **HDMI**, **Component** or **TV mode**. Operates only if the video signal is NTSC.

Dynamic Contrast AHCT

MENU → ▼ → ENTER → **[Picture]** → ▼ → ▼ → ▼ →▼ →▼ →▼ →▼ → ENTER → **[Dynamic Contrast]**



→ ▲ , ▼ → ENTER

Dynamic Contrast automatically detects the distribution of the visual signal and adjusts to create an optimum contrast.

Downloaded From TV-Manual.com Manuals

1. Off
2. On

Lamp Control AHCT

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ → ▼ →▼ →▼ →▼ →▼ →▼ → ENTER → [Lamp Control]

→ ◄, ► → ENTER

Adjusts the inverter lamp in order to reduce energy consumption.

Note

This function does not operate when Dynamic Contrast is set to On in PC, DVI, AV, HDMI, Component, TV, or MagicInfo modes. (MagicInfo : Applicable to the CXN-2 model only).

Brightness Sensor AHCT

MENU → ▼ → ENTER → [Picture] → ▼ → ▼ → ▼ →▼ →▼ →▼ →▼ →▼ →▼ → ENTER → [Brightness Sensor]



→ ▲ , ▼ → ENTER

Brightness Sensor automatically detects distribution of the inputted visual signal and adjusts to create optimum brightness.

1. Off
2. On

Sound

Available Modes

- P PC / DVI
- A AV
- C Component
- H HDMI
- M MagicInfo
- T TV

Downloaded From TV-Manual.com Manuals

Mode PACHMT

MENU → ▼ →▼ → ENTER → [Sound] → ENTER → [Mode]

→ ▲ , ▼ → ENTER

The LCD Display has a built-in high fidelity stereo amplifier.

1. **Standard**

   Selects **Standard** for the standard factory settings.

2. **Music**

   Selects **Music** when watching music videos or concerts.

3. **Movie**

   Selects **Movie** when viewing movies.

4. **Speech**

   Selects **Speech** when watching a show that is mostly dialog (i.e., news).

5. **Custom**

   Selects **Custom** if you want to adjust the settings according to your personal preferences.

Custom PACHMT

The sound settings can be adjusted to suit your personal preferences.

MENU → ▼ →▼ → ENTER → [Sound] →▼→ ENTER → [Custom]

Note

- You can hear the sound even when sound value is set to 0.
- If you adjust sound using **Custom** function, **Mode** will turn to **Custom** mode.

Bass

MENU → ▼ →▼ → ENTER → [Sound] →▼→ ENTER → [Custom]→ENTER→ [Bass]

→ ◄, ► → ENTER

Emphasizes low frequency audio.

Downloaded From TV-Manual.com Manuals

Treble

MENU → ▼ →▼ → ENTER → [Sound] →▼→ ENTER → [Custom] → ▼ → ENTER → [Treble]

→ ◄, ► → ENTER

Emphasizes high frequency audio.

Balance

MENU → ▼ →▼ → ENTER → [Sound] →▼→ ENTER → [Custom] → ▼ → ▼ → ENTER → [Balance]

→ ◄, ► → ENTER

Allows you to Adjusts the sound balance between the left and right speakers.

Auto Volume PACHMT

MENU → ▼ →▼ → ENTER → [Sound] →▼→▼→ ENTER → [Auto Volume]

→ ▲ , ▼ → ENTER

Reduces the difference in volume control between broadcasters.

1. Off
2. On

SRS TS XT PACHMT

MENU → ▼ →▼ → ENTER → [Sound] →▼→▼→▼→ ENTER → [SRS TS XT]

→ ▲ , ▼ → ENTER

SRS TS XT is a patented SRS technology that solves the problem of playing 5.1 multi-channel content over two speakers. TruSurround XT delivers a compelling, virtual

Downloaded From TV-Manual.com Manuals

surround sound experience through any two-speaker playback system, including internal television speakers. It is fully compatible with all multichannel formats.

1. **Off**
2. **On**

Sound Select PACHM

MENU → ▼ → ▼ → ENTER → **[Sound]** → ▼ →▼ → ▼ → ▼ → ENTER → [Sound Select]

→ ▲ , ▼ → ENTER

Selects either Main or Sub when **PIP** is **On**.

Note

Available Modes: **PIP ON**

1. **Main**
2. **Sub**

Speaker Select PACHM

MENU → ▼ → ▼ → ENTER → **[Sound]** → ▼ →▼ → ▼ → ▼ → ENTER → [Sound Select]

→ ▲ , ▼ → ENTER

When you use the product with it connecting to a Home theater, turn the internal speakers off so you can listen to sound from the Home theater's (external) speakers.

1. **Internal** : Sound is outputted both from the **Internal** speaker and the **External** speakers, but the volume control is only available from the **Internal** speaker.
2. **External** : When sound is only outputted from the **External** speakers, the volume control is also only available from the **External** speakers.

Downloaded From TV-Manual.com Manuals

Setup

Available Modes

- P PC / DVI
- A AV
- C Component
- H HDMI
- M MagicInfo
- T TV

Language P A C H M T

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ENTER → **[Language]**

→ ▲ , ▼ → ENTER

You can choose one of 13 languages.

English,Deutsch,Español,Français,Italiano,Svenska,Русский
Português,Türkçe, 简体中文, 繁體中文, 日本語, 한국어

Note

The language chosen affects only the language of the OSD. It has no effect on any software running on the computer.

Time P A C H M T

Selects from one of 4 time settings, **Clock Set**, **Sleep Timer**, **On Timer**, and **Off Timer**.

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼ → ENTER → **[Time]**

Clock Set

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼ → ENTER → **[Time]**→ ENTER→ **[Clock Set]**

Downloaded From TV-Manual.com Manuals

→ ▲ , ▼ → ◄, ► → ENTER

Current Time Setting.

Sleep Timer

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼ → ENTER → **[Time]**→ ▼ → ENTER→ **[Sleep Timer]**

→ ▲ , ▼ → ENTER

Turns the LCD Display off automatically at certain times.

1. **Off**
2. **30**
3. **60**
4. **90**
5. **120**
6. **150**
7. **180**

On Timer

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼ → ENTER → **[Time]**→ ▼→ ▼ → ENTER→ **[On Timer]**



→ ▲ , ▼ / ◄, ► → ENTER

Turns the LCD Display on automatically at a preset time. Controls the mode and the volume level at the time the LCD Display turns on automatically.

Off Timer

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼ → ENTER → **[Time]**→ ▼→ ▼→ ▼ → ENTER → **[Off Timer]**

Downloaded From TV-Manual.com Manuals



→ ▲ , ▼ / ◀, ▶ → ENTER

Turns the LCD Display off automatically at a preset time.

Menu Transparency PACHMT

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼ → ENTER → **[Menu Transparency]**

→ ▲ , ▼ → ENTER

Change the transparency of the background of the OSD.

1. **High**
2. **Medium**
3. **Low**
4. **Opaque**

Safety Lock PACHMT

Change PIN

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼ → ENTER → [Safety Lock]→ ENTER → [Change PIN]



→ [0~9] → [0~9] → [0~9] → [0~9]

The password can be changed.

Downloaded From TV-Manual.com Manuals

Note

The preset password for the LCD Display is "0000".

Lock On

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼ → ENTER → [Safety Lock] → ▼ → ENTER → [Lock On]



→ [0~9] → [0~9] → [0~9] → [0~9]

This is the function that locks the OSD in order to keep the current settings or to prevent others from adjusting the settings.

Energy Saving P A C H M T

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ENTER → **[Energy Saving]**

→ ▲ , ▼ → ENTER

This feature adjusts the power consumption of the unit in order to save energy.

1. **Off**
2. **On**

Video Wall P A H C T

A **Video Wall** is a set of video screens connected together, so that each screen shows a part of the whole picture or where the same picture is repeated on each screen.

When the **Video Wall** is on, you can adjust the **Video Wall** screen setting.

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ENTER → **[Video Wall]**

Note

When **Video Wall** is running, the **Auto Adjustment**, **Image Lock**, and **Size** functions are not available. **Video Wall** does not operate in **MagicInfo** mode.

Downloaded From TV-Manual.com Manuals

Video Wall

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ENTER → **[Video Wall]**→ ENTER → **[Video Wall]**



→ ▲ , ▼ → ENTER

Turns Off/On the **Video Wall** function of the selected display Off/On.

1. **Off**
2. **On**

Format

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ENTER → **[Video Wall]**→ ▼ → ENTER → **[Format]**



→ ▲ , ▼ → ENTER

The **Format** can be selected to see a divided screen.

1. **Full**

   Provides a full screen without any margins.

2. **Natural**

   Displays a natural image with the original aspect ratio intact.

Horizontal

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ENTER → **[Video Wall]**→ ▼ → ▼ → ENTER → **[Horizontal]**

Downloaded From TV-Manual.com Manuals

→ ▲ , ▼ → ENTER

Sets how many parts the screen should be divided horizontally.

Five adjustment levels: 1, 2, 3, 4, and 5.

Vertical

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ENTER → **[Video Wall]**→ ▼ → ▼ → ▼ → ENTER → **[Vertical]**

→ ▲ , ▼ → ENTER

Sets how many parts the screen should be divided vertically.

Five adjustment levels: 1, 2, 3, 4, and 5.

Screen Divider

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ENTER → **[Video Wall]**→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Screen Divider]**

The screen can be divided into several images. A number of screens can be selected with a different layout when dividing.

- Select a mode in Screen Divider.
- Select a display in Display Selection.
- The selection will be set up by pressing a number in the selected mode.

Downloaded From TV-Manual.com Manuals

Safety Screen P A C H M T

The **Safety Screen** function is used to prevent afterimages that may appear when a still picture is displayed on the screen over a long time.

- The **Safety Screen** function scrolls the screen for the specified period of time.
- This function is not available when the power is turned off.

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**

Pixel Shift

Pixel Shift

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ENTER → **[Pixel Shift]**→ ENTER → **[Pixel Shift]**→ ▲ , ▼ → ENTER

To prevent after-images on the screen, you can use this function to have pixels move on the LCD in the horizontal or vertical direction.

1. **Off**
2. **On**

Horizontal

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ENTER → **[Pixel Shift]**→ ▼ → ENTER → **[Horizontal]**→ ▲ , ▼ → ENTER



Sets how many pixels the screen moves horizontally.

Five adjustment levels: 0, 1, 2, 3, and 4.

Vertical

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ENTER → **[Pixel Shift]**→ ▼ →▼ → ENTER → **[Vertical]**→ ▲ , ▼ → ENTER

Downloaded From TV-Manual.com Manuals



Sets how many pixels the screen moves vertically.

Five adjustment levels: 0, 1, 2, 3, and 4.

Time

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ENTER → **[Pixel Shift]**→ ▼ →▼ →▼ → ENTER → **[Time]**→ ▲ , ▼ → ENTER



Set the time interval for performing the horizontal or vertical movement, respectively.

Timer

Timer

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ENTER → **[Timer]**→ ENTER → **[Timer]**→ ▲ , ▼ → ENTER

You can set the timer for Screen Burn Protection.

If you start the operation to erase any residual image, the operation will be performed for the set period of time and then automatically finish.

1. **Off**
2. **On**

Mode

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ENTER → **[Timer]**→ ▼ → ENTER → **[Mode]**→ ▲ , ▼ → ENTER

Downloaded From TV-Manual.com Manuals

You can change the **Safety Screen** Type.

1. **Scroll**
2. **Bar**
3. **Eraser**

Period

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ENTER → **[Timer]**→ ▼ → ▼ → ENTER → **[Period]**→ ▲ , ▼ → ENTER

Use this function to set the execution period for each mode set in the timer.

Time

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ENTER → **[Timer]**→ ▼ → ▼ → ▼ → ENTER → **[Time]**→ ▲ , ▼ → ENTER



Within the set period of time specify a time for execution.

- **Mode - Scroll** : 1~5 **sec**
- **Mode - Bar, Eraser** : 10~50 **sec**

Scroll

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ▼ → ENTER → **[Scroll]**

Downloaded From TV-Manual.com Manuals



This function helps to remove after-images on the screen by moving all the pixels on the LCD according to a pattern.

Use this function when there are remaining after-images or symbols on the screen, especially when you displayed a still image on the screen for a long time.

Bar

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ▼ → ▼ →ENTER → **[Bar]**



This function prevents after-images on the screen by moving long black and white vertical lines.

Eraser

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ▼ → ▼ → ▼ →ENTER → **[Eraser]**



This function prevents after-images on the screen by moving a rectangular pattern.

Side Gray

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ENTER → **[Safety Screen]**→ ▼ → ▼ → ▼ → ▼→ ▼ →ENTER → **[Side Gray]**

Downloaded From TV-Manual.com Manuals

→ ▲ , ▼ → ENTER

Select the brightness of the grey for the screen background.

1. **Off**
2. **Light**
3. **Dark**

Resolution Select P

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ▼ →ENTER → **[Resolution Select]**



→ ▲ , ▼ → ENTER

When the picture is not displayed properly on the screen when setting the graphics card resolution of the computer to 1024 x 768 @ 60Hz, 1280 x 768 @ 60Hz, 1360 x 768@ 60Hz, 1366 x 768 @ 60Hz by using this function(Resolution Select), you can have the picture displayed on the screen in the specified resolution.

Note

Available in **PC** mode only

1. **Off**
2. **1024 X 768**
3. **1280 X 768**
4. **1360 x 768**
5. **1366 X 768**

Note

Selecting the menu is only allowed when the graphics resolution is set to 1024 x 768 @ 60Hz, 1280 x 768 @ 60Hz, 1360 x 768@ 60Hz, 1366 x 768 @ 60Hz.

Downloaded From TV-Manual.com Manuals

Power On Adjustment PACHMT

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ▼ →▼→ ENTER → **[Power On Adjustment]**



→ ▲ , ▼ → ENTER

Adjusts the Power On time for the screen.

OSD Rotation PACHMT

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ▼ →▼→ ▼→ ▼→ ▼→ ▼→ ENTER → **[OSD Rotation]**

→ ▲ , ▼ → ENTER

OSD Rotate

1. **Landscape**
2. **Portrait**

Reset

Reverts the product settings to factory defaults. The Reset function is only available when **PC** / **DVI** is being used.

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ▼ →▼→ ▼→ ▼→ ENTER → **[Reset]**

Image Reset P

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ▼ →▼→ ▼→ ▼→ ENTER → **[Reset]**→ ENTER → **[Image Reset]**

Downloaded From TV-Manual.com Manuals



→ ◄, ►→ ENTER

Note

Available in **PC** mode only

Note

The Reset function is not available when **Video Wall** is **On**.

Color Reset PACHMT

MENU → ▼ →▼ →▼ → ENTER → **[Setup]** → ▼→ ▼→ ▼→ ▼ → ▼ → ▼ → ▼ → ▼ →▼→ ▼→ ▼→ ENTER → **[Reset]**→ ▼→ ENTER → **[Color Reset]**



→ ◄, ► → ENTER

Multi Control

Available Modes

- P PC / DVI
- A AV
- C Component
- H HDMI
- M MagicInfo
- T TV

Note

MagicInfo supports the CXN-2 model only.

Multi Control PACHMT

Assigns an individual ID to the SET.

Downloaded From TV-Manual.com Manuals

MENU → ▼ →▼ →▼ → ▼ → ENTER → [Multi Control]→ ENTER



→ ▲ , ▼ → [0~9]

- ID Setup

  Assigns distinctive IDs to the SET.

- ID Input

  Use to select the transmitter functions of the individual SET. Only a SET where the ID corresponds to the transmitter setting becomes activated.

MagicInfo

Available Modes

- P PC / DVI
- A AV
- C Component
- H HDMI
- M MagicInfo
- T TV

Note

MagicInfo supports the CXN-2 model only.

Note

- The remote control can be used to select MagicInfo. However, it is recommended to use a separate USB keyboard to utilize MagicInfo fully.
- For MagicInfo in Device mode, moving external devices while booting may cause errors. Set up external devices only if the LCD Display turns on.
- Do not unplug the LAN cable used for the network (ex: video display). Otherwise, the program (MagicInfo) may stop. If you do unplug the cable, restart the system.
- Do not unplug the LAN cable used by an USB device (ex: video display). Otherwise, the program (MagicInfo) may stop.
- To access other sources, press the SOURCE button in MagicInfo.
- The preset password for the LCD Display is "000000".

Downloaded From TV-Manual.com Manuals

- The server program's Power-On option works only if the LCD Display's power is completely shut off.

  Please make sure not to use the Power-On option when the LCD Display is in the process of shutting down since this may cause system errors on the LCD Display.

- When using **MagicInfo** with the MagicInfo Server Program: perform Network mode.
- When using **MagicInfo** with the device directly connected to LCD Display : execute Device mode.
- Press ALT + ESC to directly go to the **MagicInfo** Window screen.
- To setup **MagicInfo** on a Windows screen, a keyboard and mouse are required.
- To setup **MagicInfo** on a Windows screen, refer to the MagicInfo Server Help.

  It is highly recommended not to turn off the AC power during an operation.

- For pivoted LCD Displays, ticker transparency is not supported.
- For pivoted LCD Displays, a screen resolution of up to 720*480(SD) is supported for movies.
- For drive D:, **EWF** is not applied.
- To save Setup contents that have been changed when EWF is in the Enable state,you must Commit them.
- By selecting **Disable**, **Enable** or **Commit**, the system is restarted.

MagicInfo

1. Select Application - step 1



You can select an Application to be executed in your computer when Windows starts.

2. Select TCP/IP - step 2

Downloaded From TV-Manual.com Manuals


MagicInfo Setup Wizard - v.1.03
Select TCP/IP - step 2
Obtain an IP address automatically
Use the following IP address:
1 Iuput
IP address: 10 . 88 . 68 . 107
Subnet mask: 255 . 255 . 255 . 0
Default gateway: 10 . 88 . 68 . 1
Obtain DNS server address automatically
Use the following DNS server address:
Preferred DNS server: 10 . 41 . 131 . 60
Alternate DNS server: 165 . 213 . 245 . 161
2 Click
< Back(B)
Next(N) >
Finish
Cancel

In step 2 of MagicInfo Setup Wizard, you don't have to go to Network Setting on the desktop to make your settings for TCP/IP. You just do that at step 2 of MagicInfo installation.

3. Select Language - step 3

When using multiple languages, you can choose and set a specific language among them.

4. Select Screen Type - step 4

Downloaded From TV-Manual.com Manuals



You can select which rotation type will be applied to your device.

5. Setup Information



Shows the settings that have been selected by the user

Note

If the **MagicInfo** icon is not displayed on the notification area, double click the **MagicInfo** icon on the window desktop. The icon will appear.

D.Menu

Available Modes

- P PC / DVI
- A AV
- H HDMI

Downloaded From TV-Manual.com Manuals

- MagicInfo
- TV

Note

MagicInfo supports the CXN-2 model only.

Picture

Size



You can switch the Size.

Press the *TOOLS* button to display the **Tools** menu. You can also set the size by selecting **Tools** → **Picture Size**.

1. **Auto Wide**

   Automatically adjusts the picture size to the "16:9" aspect ratio.

2. **16:9**

   Adjusts the picture size to 16:9 appropriate for DVDs or wide broadcasting.

3. **Wide Zoom**

   Magnify the size of the picture more than 4:3.

4. **Zoom**

   Magnifies the 16:9 wide picture (in the vertical direction) to fit the screen size.

5. **4:3**

   Sets the picture to 4:3 normal mode.

6. **Screen Fit**

   Use the function to see the full image without any cutoff when HDMI (720p/1080i/1080p), Component (1080i / 1080p) signals are input.

Note

Wide Zoom : Press the ▶ button to Select Position, then press the ENTER button. Press the ▲ or ▼ button to move the picture up / down. Then press the ENTER button.

Zoom : Press the ▶ button to Select Position, then press the ENTER button. Press the ▲ or ▼ button to move the picture up and down. Then press the ENTER button. Press the ▶ button to Select Size, then press the ENTER button. Press the ▲ or ▼ button

Downloaded From TV-Manual.com Manuals

to magnify or reduce the picture size in the vertical direction. Then press the ENTER button.

After selecting **Screen Fit** in HDMI (1080i / 1080p) or Component (1080i / 1080p) mode: Select Position by pressing the ◄ or ► button. Use the ▲ or ▼ , ◄ or ► button to move the picture.

- **Reset** : Press the ◄ or ► button to select **Reset**, then press the ENTER button. You can initialize the setting.

Depending on the input source, the picture size options may vary.

Settings can be adjusted and stored for each external device you have connected to an input of the TV.

Temporary image retention may occur when viewing a static image on the set for more than two hours.

Screen Mode



Only when setting the **picture size** to **Auto Wide** can the user determine the **Screen mode**. Each individual European country requires a different picture size so this function is intended to help users to select it.

1. **16:9**

   Sets the picture to 16:9 wide mode.

2. **Wide Zoom**

   Magnify the size of the picture more than 4:3.

3. **Zoom**

   Magnify the size of the picture vertically.

4. **4:3**

   Sets the picture to 4:3 normal mode.

Note

Picture Size is available in **Auto Wide** mode

This function is not available in **PC** or **Component**, **HDMI** mode.

Downloaded From TV-Manual.com Manuals

Sound

Audio Language

You can change the default value for audio languages. Displays the language information for the incoming stream.

Note

While viewing a digital channel, this function can be selected.

You can only select the language among the actual languages being broadcast.

Audio Format



When sound is emitted from both the main speaker and the audio receiver, a sound echo may occur due to the decoding speed difference between the main speaker and the audio receiver. In this case, use the TV Speaker function.

- MPEG
- Dolby Digital

Note

While viewing a digital channel, this function can be selected.

The **Audio Format** appears according to the broadcasting signal.

Audio Description



Downloaded From TV-Manual.com Manuals

This is an auxiliary audio function that provides an additional audio track for visually challenged persons. This function handles the Audio Stream for the AD (**Audio Description**), when it is sent along with the Main audio from the broadcaster. Users can turn the **Audio Description** On or Off and control the volume.

Audio Description

Turn the audio description function on or off.

Volume

You can adjust the audio description volume.

Note

Volume is active when **Audio Description** is set to On.

While viewing a Digital channel, this function can be selected.

Channel

Note

The default setting may be different depending on the selected Input Mode (input signal source selected in External Input List) and the selected resolution.

Country

Select the country in which the product is being used before you use the **Auto Store** feature. If you do not see your country in the list, select Others.

Digital Channel

You can change the country for digital channels.

Analogue Channel

You can change the country for analogue channels.

Note

The PIN number input screen appears. Enter your 4 digit PIN number.

Auto Store



Downloaded From TV-Manual.com Manuals

You can scan for the frequency ranges available to you (and availability depends on your country).

Automatically allocated programme numbers may not correspond to actual or desired programme numbers.

Note

If a channel is locked using the **Child Lock** function, the PIN input window appears.

Air / Cable

Antenna source to memorize.

- **Digital & Analogue** : Digital and Analogue channels.
- **Digital** : Digital channels.
- **Analogue** : Digital channels.

When selecting **Cable** → **Digital & Analogue** or **Cable** → **Digital** : Provide a value to scan for cable channels.

- **Search Mode** : **Network** / **Full** / **Quick**

Note

Scans for all channels with active broadcast stations and stores them in the TV`s memory.

Quick

- **Search Mode** : Displays the network identification code.
- **Frequency (Start~Stop)** : Displays the frequency for the channel. (Differs in each country)
- **Modulation** : Displays available modulation values.
- **Symbol Rate** : Displays available symbol rates.

Manual Store



You can scan the frequency ranges available on your television in your area and store all the channels found manually.

Digital Channel

Manual store for digital channels.

- **Channel** : Set the Channel number using the ▲ , ▼ or number (0~9) buttons

Downloaded From TV-Manual.com Manuals

- **Frequency** : Set the frequency using the number buttons.
- **Bandwidth** : Set the bandwidth using the ▲ , ▼ or number (0~9) buttons.

Note

Digital Channel is only available in DTV mode.

When it has finished, channels are updated in the channel list.

Analogue Channel

Manual store for analogue channel.

- **Programme** (**Programme** number to be assigned to a channel)

  Inputting the appropriate program number on the screen. Sets the programme number using the ▲ , ▼ or number (0~9) buttons

- **Colour System**

  Adjusts repeatedly until the colour is of the best quality. Sets the colour system value using the ▲ or ▼ button.

  (**Auto** / **PAL** / **SECAM** / **NTSC4.43**)

- **Sound System**

  Adjusts repeatedly until the sound is of the best quality. Sets the sound system value using the ▲ or ▼ button.

  (**BG** / **DK** / **I** / **L**)

- **Channel** (When you know the number of the channel to be stored)

  You can store television channels, including those received via cable networks.

  When storing channels manually, you can choose:

  Whether or not to store each of the channels found. The Programme number of each stored channel which you wish to identify

  - **C** (Air channel mode): You can select a channel by entering the assigned number to each air broadcasting station in this mode.

  - **S** (Cable channel mode): You can select a channel by entering the assigned number for each cable channel in this mode.

- **Search** (When you do not know the channel numbers)

  Press the ▲ or ▼ button to start the search. The tuner scans the frequency range until the first channel or the channel that you selected is received on your screen.

- **Store** (When you store the channel and associated programme number)

  It's used to restore the number user inputs. Set to OK by pressing the ENTER ↵ button.

Downloaded From TV-Manual.com Manuals

Cable Search Option



Using this function, you can manually add the channel range to be scanned by full search mode of the **Auto Store** function.

- **Frequency (Start ~ Stop)** : Set the start frequency / Set the stop frequency (Differs in each country)
- **Modulation** : Displays available modulation values.
- **Symbol Rate** : Displays available symbol rates.

Now & Next Guide / Full Guide / Default Guide

The EPG (Electronic Programme Guide) information is provided by the broadcasters. Programme entries may appear blank or out of date as a result of the information broadcast on a given channel. The display will dynamically update as soon as new information becomes available

Note

You can also display the guide menu simply by pressing the GUIDE button. (To configure the **Default Guide**, refer to the descriptions.).

Now & Next Guide

For the six channels indicated in the left-hand column, displays the Current programme and the Next programme information.

Downloaded From TV-Manual.com Manuals

Full Guide



Displays the programme information as time ordered One hour segments. Two hours of programme information is displayed which may be scrolled forwards or backwards in time.

To...	Then...
Watch a programme in the EPG list.	Select a programme by pressing the ▲ , ▼ , ◄ , ► button. Press the ENTER ↵ button.
If the next programme is selected, it is scheduled with the clock icon displayed. If the ENTER ↵ button is pressed again, the scheduling is cancelled with the clock icon gone. For details about scheduling programmes, refer to the next page.	
View programme information	Select a programme of your choice by pressing the ▲ , ▼ , ◄ , ► button. Press the INFO button when the programme of your choice is highlighted.
Toggle between the **Now & Next Guide** or **Full Guide**	Press the red button repeatedly.
Scrolls backwards quickly (24 hours)	Press the green button repeatedly.
Scrolls forward quickly (24 hours)	Press the yellow button repeatedly.
Exit the guide	Press the EXIT button.

Note

The programme title is on the upper part of the screen center. Please click on *INFO* button for the detailed information. Channel Number, Running Time, Status Bar, Parental Level, Video Quality Information(HD/SD), Sound Modes, Subtitle or Teletext, Languages of Subtitle or Teletext, and brief summary of the highlighted programme are included on the detailed information.

"... " will be appeared if the summary is long.

Six channels are displayed. To scroll between channels, move to a channel using the ▲ or ▼ button. To display page by page, use the P∧ , or P∨ button.

Default Guide

You can decide whether to display either the **Now & Next Guide** or the **Full Guide** when the *GUIDE* button on the remote control is pressed.

Downloaded From TV-Manual.com Manuals

- **Now & Next / Full Guide**

Channel List



Using this menu, you can add / delete or set favourites channels and use the programme guide for digital broadcasts.

You can select these options by simply pressing the *CH LIST* button on the remote control.

All Channels

Shows all currently available channels.



Added Channels

Shows all added channels.

Favourites

Shows all favourite channels.

Note

To select the favourites channels you have set up, press the FAV.CH button on the remote control.

When it has finished, channels are updated in the channel list

Programmed

Shows all current reserved programmes.

Note

Select a channel in the All Channels, **Added Channels** or **Favourites** screen by pressing the ▲ , ▼ buttons, and pressing the ENTER button. Then you can watch the selected channel.

Using the Colour buttons with the **Channel List**.

Downloaded From TV-Manual.com Manuals

- Red (**Channel Type**) : Toggle between your TV, Radio, Data / Other and All.
- Green (**Zoom**) : Enlarges or shrinks a channel number.
- Yellow (**Select**) : Selects multiple channel lists. You can perform the add/delete or add to favourites/delete from favourites function for multiple channels at the same time. Select the required channels and press the yellow button to set all the selected channels at the same time. The ✓ mark appears to the left of the selected channels.
- *TOOLS* (**Tools**) : Displays the **Delete** (or **Add**), **Add to Favourite** (or **Delete from Favourite**), **Lock** (or **Unlock**), **Timer Viewing**, **Edit Channel Name**, **Edit Channel Number**, **Sort**, **Select All**, **Deselect All** or **Auto Store** menu. (The Options menus may differ depending on the situation.)

Channel Status Display Icons

- A :An Analogue channel.
- ✓ : A channel selected by pressing the yellow button.
- ♥ : A channel set as a **Favourite**.
- : A programme currently being broadcast.
- : A locked channel.
- : A reserved programme.

Channel List Option Menu (in All Channels / Added Channels / Favourites)



Add / Delete

- You can delete or add a channel to display the channels you want.

  Note

  All deleted channels will be shown on **All Channels** menu.

  A gray-coloured channel indicates the channel has been deleted.

  The **Add** menu only appears for deleted channels.

  You can also delete a channel to the **Added Channels** or **Favourites** menu in the same manner.

Add to Favourite / Delete from Favourite

- You can set channels you watch frequently as favourites.

Downloaded From TV-Manual.com Manuals

Press the *TOOLS* button to display the **Tools** menu. You can also set the add to (or delete from) **Favourite** by selecting **Tools** → **Add to Favourite** (or **Delete** from **Favourite**)

Note

The icon symbol will be displayed and the channel will be set as a favourite.

All favourite channels will be shown on **Favourites** menu.

Lock / Unlock

- You can lock a channel so that the channel cannot be selected and viewed.

  Note

  This function is available only when the **Child Lock** is set to **On**.

  The PIN number input screen appears. Enter your 4 digit PIN number.

  The default PIN number of a new TV set is 0-0-0-0. You can change the PIN, by selecting **Change PIN** from the menu.

  The Icon symbol will be displayed and the channel will be locked.

Timer Viewing

- If you reserve a programme you want to watch, the channel is automatically switched to the reserved channel in the **Channel List**; even when you are watching another channel. To reserve a programme, set the current time first.

  Note

  Only memorized channels can be reserved.

  You can set the channel, day, month, year, hour and minute directly by pressing the number buttons on the remote control.

  Reserving a programme will be shown in the **Programmed** menu.

  Digital Programme Guide and Viewing Reservation - When a digital channel is selected, and you press the ▶ button, the Programme Guide for the channel appears. You can reserve a programme according to the procedures described above.

Edit Channel Name (analogue channels only)

- Channels can labelled so that their call letters appear whenever the channel is selected.

  Note

  The names of digital broadcasting channels are automatically assigned and cannot be labelled.

Edit Channel Number (digital channels only)

- You can also edit the channel number by pressing the number buttons on the remote control.

Downloaded From TV-Manual.com Manuals

Sort (analogue channels only)

- This operation allows you to change the programme numbers of the stored channels.

  This operation may be necessary after using the auto store.

Select All / Deselect All

- Channels can labelled so that their call letters appear whenever the channel is selected.

  - **Select All** : You can select all the channels in the channel list.
  - **Deselect All** : You can deselect all the selected channels.

Note

You can only select **Deselect All** when there is a selected channel.

Auto Store

- **Note**

  For detailed procedures on setting up options, refer to the **Channel** Menu instructions.

  If a channel is locked using the **Child Lock** function, the PIN input window appears.

Channel List Option Menu (in Programmed)

You can view, modify or delete a reservation

Note

Press the *TOOLS* button to use the option menu.



Change Info

- Select to change a viewing reservation.

Cancel Schedules

- Select to cancel a viewing reservation.

Information

- Select to view a viewing reservation. (You can also change the reservation information.)

Downloaded From TV-Manual.com Manuals

Select All

- Select all reserved programmes.

Channel Mode

When press the ∨ P ∧ button, Channels will be switched within the selected channel list.



- **Added Ch** : Channels will be switched within the memorized channel list.
- **Favourite Ch** : Channels will be switched within the favourite channel list.

Fine Tune



If the reception is clear, you do not have to fine tune the channel, as this is done automatically during the search and store operation. If the signal is weak or distorted, you may have to fine tune the channel manually.

Note

Fine tuned channels that have been saved are marked with an asterisk " * " on the right-hand side of the channel number in the channel banner.

To reset the fine-tuning, select **Reset** by pressing the ▲ or ▼ button and then press the ENTER ↵ button.

Only Analogue TV channels can be fine tuned.

Setup

Note

The default setting may be different depending on the selected Input Mode (input signal source selected in External Input List) and the selected resolution.

Downloaded From TV-Manual.com Manuals

Plug & Play

When the TV is initially powered on, several basic settings proceed automatically and sub sequently. the following settings are available.

Menu Language



You can set the menu language.

The language chosen affects only the language of the OSD.

Broadcast



Subtitle

You can activate and deactivate the subtitles. Use this menu to set the **Mode**.

Normal under the menu is the basic subtitle and **Hard of hearing** is the subtitle for a hearing-impaired person.

Subtitle

Switches subtitles **on** or **off**.

Mode

Sets the subtitle mode.

- **Normal** / **Hard of hearing**

Downloaded From TV-Manual.com Manuals

Subtitle Language

Set the subtitle language.

Note

If the programme you are watching does not support the **Hard of hearing** function, **Normal** automatically activates even though **Hard of hearing** mode is selected.

English is the default in cases where the selected language is unavailable in the broadcast.

You can select these options simply by pressing the *SUBT.* button on the remote control.

Digital Text

If the programme is broadcast with digital text, this feature is enabled.

- **Disable** / **Enable** (UK only)

Note

MHEG (Multimedia and Hypermedia Information Coding Experts Group)

An International standard for data encoding systems used in multimedia and hypermedia. This is at a higher level than the MPEG system which includes data-linking hypermedia such as still images, character service, animation, graphic and video files as well as multimedia data. MHEG is user runtime interaction technology and is being applied to various fields including VOD (Video-On-Demand), ITV (Interactive TV), EC (Electronic Commerce), tele-education, tele-conferencing, digital libraries and network games.

Preference

Primary Audio Language / **Secondary Audio Language** / **Primary Subtitle Language** / **Secondary Subtitle Language** / **Primary Teletext Language** /**Secondary Teletext Language**

Using this feature, users can select one of the languages. The language selected here is the default when the user selects a channel.

If you change the language setting, the **Subtitle Language**, **Audio Language**, and the **Teletext Language** of the **Language** menu are automatically changed to the selected language.

The **Subtitle Language**, **Audio Language**, and the **Teletext Language** of the **Language** menu show a list of languages supported by the current channel and the selection is highlighted.

If you change this language setting, the new selection is only valid for the current channel. The changed setting does not change the setting of the **Primary Subtitle Language**, **Primary Audio Language**, or the **Primary Teletext Language** of the **Preference** menu.

Downloaded From TV-Manual.com Manuals

Common Interface

CI Menu

This enables the user to select from the CAM-provided menu.

Select the **CI Menu** based on the menu PC Card.

Application Info.

This contains information on CAM inserted in the CI slot and displays it.

The Application Info inserting is about the CI CARD. You can install the CAM anytime whether the TV is ON or OFF.

Security



Child Lock

This feature allows you to prevent unauthorized users, such as children, from watching unsuitable programme by muting out video and audio.

- **Off** / **On**

Note

Before the setup screen appears, the PIN number input screen appears. Enter your 4 digit PIN number.

The default PIN number of a new TV set is 0-0-0-0. You can change the PIN by selecting **Change PIN** from the menu.

You can lock some channels in **Channel List.**

Child Lock is available only in **TV** mode.

Parental Lock

This feature allows you to prevent unauthorized users, such as children, from watching unsuitable programme by a 4-digit PIN (Personal Identification Number) code that is defined by the user.

- **Allow All** : Press to unlock all TV ratings.
- **Block All** : Press to lock all TV ratings.

Downloaded From TV-Manual.com Manuals

Note

Before the setup screen appears, the PIN number input screen appears. Enter your 4 digit PIN number.

The default PIN number of a new TV set is 0-0-0-0. You can change the PIN by selecting **Change PIN** from the menu.

When the parental ratings are set, the symbol is displayed.

Change PIN

You can change your personal ID number that is required to set up the TV.

Note

Before the setup screen appears, the PIN number input screen appears. Enter your 4digit PIN number.

The default PIN number of a new TV set is 0-0-0-0.

If you forget the PIN code, press the remote control buttons in the following sequence, which resets the PIN to 0-0-0-0: *POWER* (Off) → *MUTE* → 8 → 2 → 4 → *POWER* (On).

Support

Signal Information (digital channels only)



Unlike analogue channels, which can vary in reception quality from snowy to clear, digital (HDTV) channels have either perfect reception quality or you will not receive them at all. So, unlike analogue channels, you cannot fine tune a digital channel. You can, however, adjust your antenna to improve the reception of available digital channels.

Note

If the signal strength meter indicates that the signal is weak, physically adjust your antenna to increase the signal strength. Continue to adjust the antenna until you find the best position with the strongest signal.

Software Upgrade



Downloaded From TV-Manual.com Manuals

Samsung may offer upgrades for TV‘s firmware in the future.

Downloaded From TV-Manual.com Manuals

Troubleshooting

Self-Test Feature Check

Note

Check the following items yourself before calling for assistance. Contact a Service Center for problems that you cannot solve by yourself.

Self-Test Feature Check

1. Turn off both your computer and the LCD Display.
2. Unplug the video cable from the back of the computer.
3. Turn on the LCD Display.

   The figure shown below ("**Check Signal Cable**") appears on a black background when the LCD Display is working normally even though no video signal is detected: While in the Self-Test mode, the LED power indicator remains green and the figure moves around on the screen.

4. Turn off your LCD Display and reconnect the video cable; then turn on both your computer and the LCD Display

If your LCD Display screen remains blank after using the previous procedure, check your video controller and computer system; your LCD Display is functioning properly.

Warning Messages

You can even view the screen at a resolution of 1920 x 1080. However, you will receive the following message for a minute; You can choose to change the screen resolution or stay in the current mode during that time. And If the resolution is more than 85Hz, you will see the black screen because the LCD Display does not support over 85Hz.

Note

Refer to Specifications > Preset Timing Modes for the resolutions or frequencies supported by the LCD Display.

Maintenance and Cleaning

1) Maintaining the LCD Display Case.

Clean with a soft cloth after disconnecting the power cord.

Downloaded From TV-Manual.com Manuals

- Do not use benzene, thinner or other flammable substances.

2) Maintaining the Flat Panel Display Screen.

Clean with a soft cloth (cotton flannel).

- Never use acetone, benzene or thinner.

  The user is responsible for any damage caused by using these substances.

  (They may cause flaws or deformation of the screen surface.)

- The user will be required to pay costs and related expenses for repairing damages caused.

Symptoms and Recommended Actions

Note

A LCD Display recreates visual signals received from the computer. Therefore, if there is a problem with the computer or the video card, this can cause the LCD Display to become blank, have poor coloring, become noisy, etc. In this case, first check the source of the problem, and then contact a Service Center or your dealer.

1. Check if the power cord and the video cables are properly connected to the computer.
2. Check if the computer beeps more than 3 times when booting.

   (If it does, request service.)
3. If you installed a new video card or if you assembled the PC, check if you installed the Adaptor(video).
4. Check if the scanning ratio of the video screen is set to between 50 Hz ~ 85 Hz.

   (Do not exceed 60Hz when using the maximum resolution.)
5. If you have problems in installing the Adaptor (video) driver, boot the computer in Safe Mode, remove the Display Adaptor in the "Control Panel -> System -> Device Administrator" and then reboot the computer to reinstall the Adaptor (video) driver.

Check List

Note

- The following table lists possible problems and their solutions. Before calling for assistance, check the information in this section to see if you can remedy any problems for yourself. If you do need assistance, please call the phone number on the Information section or contact your dealer.
- For more network-related information, refer to the MagicInfo Troubleshooting section.

Downloaded From TV-Manual.com Manuals

Problems related to the Installation

Note

Problems related to the LCD Display installation and their solutions are listed.

PC Mode

Q: The LCD Display screen flickers.

A: Check if the signal cable between the computer and the LCD Display is securely connected.

(Refer to Connecting a Computer)

TV Mode

Q: TV screen is blurred or shows noise signals.

A: Check if the TV antenna connector is securely connected to the external antenna. (Refer to Connecting TV)

Problems related to the Screen

Note

Problems related to the LCD Display screen and their solutions are listed.

Q: The screen is blank and the power indicator is off.

A: Ensure that the power cord is firmly connected and the LCD Display is on.

(Refer to the Connecting a Computer)

Q: "**Check Signal Cable**" message.

A: Ensure that the signal cable is firmly connected to the PC or video sources.

(Refer to the Connecting a Computer)

A: Ensure that the PC or video sources are turned on.

Q: "**Not Optimum Mode**" message.

A: Check the maximum resolution and the frequency of the video Adaptor.

A: Compare these values with the data in the Preset Timing Modes Chart.

Q: The picture rolls vertically.

A: Check if the signal cable is securely connected. Re-connect it, if necessary.

(Refer to Connecting a Computer)

Q: The image is not clear; picture is blurred.

A: Run Frequency **Coarse** and **Fine** tuning.

A: Turn on again after removing all accessories (video extension cable, etc.)

A: Set the resolution and frequency to the recommended ranges.

Downloaded From TV-Manual.com Manuals

Q: The picture image is unstable and shakes.

A: Check if the resolution and frequency set for the computer video card falls in the range supported by the LCD Display. If not, reset them referring to the current Information under the LCD Display menu and Preset Timing Modes.

Q: Ghost images are shown in the picture.

A: Check if the resolution and frequency set for the computer video card falls in the range supported by the LCD Display. If not, reset them referring to the current Information under the LCD Display menu and Preset Timing Modes.

Q: The image is too light or too dark.

A: Adjust the **brightness** and **contrast**.

(Refer to the **Brightness**, **Contrast**)

Q: The screen color is inconsistent.

A: Adjust color using **Custom** under OSD Color Adjustment menu.

Q: The color image is distorted by dark shadows.

A: Adjust color using **Custom** under OSD Color Adjustment menu.

Q: The color white is poor.

A: Adjust color using **Custom** under OSD Color Adjustment menu.

Q: The Power Indicator blinks.

A: The LCD Display is currently saving the changes made in the settings to the OSD memory.

Q: The screen is blank and the power indicator light blinks every 0.5 or 1 seconds.

A: The LCD Display is using its power management system. Press any key on the keyboard.

Q: The screen is blank and it is blinking.

A: If you see the "**TEST GOOD**" message on the screen when you pressing the MENU button, check the cable connection between the LCD Display and the computer to ensure that the connector is properly connected.

Problems related to Audio

Note

Problems related to audio signals and their solutions are listed below.

Q: No sound.

A: Ensure that the audio cable is firmly connected to both the audio-in port on your LCD Display and the audio-out port on your sound card.

(Refer to the Connecting a Computer)

A: Check the volume level.

Q: The sound level is too low.

Downloaded From TV-Manual.com Manuals

A: Check the volume level.

A: If the volume is still too low after turning the control to its maximum, check the volume control on the computer sound card or software program.

Q: The sound is too high or too low.

A: Adjusts the **Treble** and **Bass** to the appropriate levels.

Problems related to the Remote Control

Note

Problems related to the remote control and their solutions are listed.

Q: The remote control buttons do not respond.

A: Check the polarities (+/-) of the batteries.

A: Check if the batteries are empty.

A: Check if the power is on.

A: Check if the power cord is securely connected.

A: Check if a special fluorescent or neon lamp is on in the vicinity.

Q & A

Q: How can I change the frequency?

A: The frequency can be changed by reconfiguring the video card.

Note

That video card support can vary, depending on the version of the driver used. (Refer to the computer or the video card manual for details.)

Q: How can I adjust the resolution?

A: Windows XP:

Set the resolution in the Control Panel → Appearance and Themes → Display → Settings.

A: Windows ME/2000:

Set the resolution in the Control Panel → Display → Settings.

* Contact the video card manufacturer for details.

Q: How can I set the Power Saving function?

A: Windows XP:

Set the resolution in the Control Panel → Appearance and Themes → Display → Screen Saver.

Set the function in the BIOS-SETUP of the computer. (Refer to the Windows / Computer Manual).

A: Windows ME/2000:

Downloaded From TV-Manual.com Manuals

Set the resolution at the Control Panel → Display → Screen Saver.

Set the function in the BIOS-SETUP of the computer. (Refer to the Windows / Computer Manual).

Q: How can I clean the outer case/LCD Panel?

A: Disconnect the power cord and then clean the LCD Display with a soft cloth, using either a cleaning solution or plain water.

Do not leave any detergent or scratches on the case. Do not let any water enter the LCD Display.

Q: How can I play the video?

A: The video supports the MPEG1 and WMV codecs only. Install the corresponding codec to play the video. Note that some of the codecs can be incompatible.

Note

Before calling for assistance, check the information in this section to see if you can remedy any problems yourself. If you do need assistance, please call the phone number on the Information section or contact your dealer.

Downloaded From TV-Manual.com Manuals

Specifications

General

General		
Model Name	SyncMaster 400CX-2, 400CXN-2 SyncMaster 460CX-2, 460CXN-2	
LCD Panel		
Size	SyncMaster 400CX-2, 400CXN-2	40 inch (101 cm)
	SyncMaster 460CX-2, 460CXN-2	46 inch (116 cm)
Display area	SyncMaster 400CX-2, 400CXN-2	885.6 mm (H) x 498.15 mm (V)
	SyncMaster 460CX-2, 460CXN-2	1018.08 mm (H) x 572.7 mm (V)
Pixel Pitch	SyncMaster 400CX-2, 400CXN-2	0.46125 mm (H) x 0.46125 mm (V)
	SyncMaster 460CX-2, 460CXN-2	0.53025 mm (H) x 0.53025 mm (V)
Synchronization		
Horizontal	30 ~ 81 kHz	
Vertical	56 ~ 85 Hz	
Display Color		
16.7 M		
Resolution		
Optimum resolution	SyncMaster 400CX-2, 400CXN-2	1920 x 1080 @ 60Hz
	SyncMaster 460CX-2, 460CXN-2	1920 x 1080 @ 60Hz
Maximum resolution	SyncMaster 400CX-2, 400CXN-2	1920 x 1080 @ 60Hz
	SyncMaster 460CX-2, 460CXN-2	1920 x 1080 @ 60Hz

Downloaded From TV-Manual.com Manuals

Input Signal, Terminated

RGB Analog, DVI(Digital Visual Interface) Compliant Digital RGB

0.7 Vp-p ±5 %

separate H/V sync, Composite, SOG

TTL level (V high ≥ 2.0 V, V low ≤ 0.8 V)

Maximum Pixel Clock

148.5MHz (Analog,Digital)

Power Supply

This product supports 100 - 240 V. Since the standard voltage may differ from country to country, please check the label on the back of the product.

Signal connectors

D-sub, DVI-D In/Out, AV(Composite,CVBS), HDMI, RS232C In/Out,PC Audio (Stereo) In, Audio In(L/R), Audio Out(Stereo), RF, LAN, USB(3 port), VGA Out (Network Model only)

Dimensions (W x H x D) / Weight

SyncMaster 400CX-2, 400CXN-2	971.0 x 582.0 x 119.0 mm / 38.2 x 22.9 x 4.7 inch (Without Stand) 971.0 x 641.5 x 311.0 mm / 38.2 x 25.3 x 12.2 inch (With Stand) / 19.3 kg / 42,5 lbs (CX-2), 21.0 kg / 47.4 lbs (CXn-2)
SyncMaster 460CX-2, 460CXN-2	1102.0 x 658.0 x 125.5 mm / 43.4 x 25.9 x 4.9 inch (Without Stand) 1102.0 x 719.0 x 311.0 mm / 43.4 x 28.3 x 12.2 inch (With Stand) / 27.0 kg / 59.5 lbs (CX-2), 28.5 kg / 62.8 lbs (CXn-2)

VESA Mounting Interface

600.0 x 400.0 mm

Environmental considerations

SyncMaster 400CXN-2, 460CXN-2	Operating	Temperature : 50°F ~ 104°F (10°C ~ 40°C) Humidity : 10 % ~ 80 %, non-condensing
	Storage	Temperature : -4°F ~ 113°F (-20°C ~ 45°C) Humidity : 5 % ~ 95 %, non-condensing
SyncMaster 400CX-2, 460CX-2	Operating	Temperature : 32°F ~ 104°F (0°C ~ 40°C) Humidity : 10 % ~ 80 %, non-condensing
	Storage	Temperature : -4°F ~ 113°F (-20°C ~ 45°C) Humidity : 5 % ~ 95 %, non-condensing

Downloaded From TV-Manual.com Manuals

Plug and Play Capability

This LCD Display can be installed on any Plug & Play compatible system. The interaction of the LCD Display and the computer systems will provide the best operating conditions and LCD Display settings. In most cases, the LCD Display installation will proceed automatically, unless the user wishes to select alternate settings.

Dot Acceptable

TFT-LCD panels manufactured by using advanced semiconductor technology with precision of 1ppm (one millionth) above are used for this product. But the pixels of RED, GREEN, BLUE and WHITE color appear to be bright sometimes or some black pixels may be seen. This is not from bad quality and you can use it without any problems.

For example, the number of TFT-LCD sub pixels contained in this product are 6,220,800.

Note

Design and specifications are subject to change without prior notice.

CX-2 - Class B Equipment (Information Communication equipment for residential use)

CXN-2 - Class A Equipment

PowerSaver

This LCD Display has a built-in power management system called PowerSaver. This system saves energy by switching your LCD Display to low-power mode when it has not been used for a certain amount of time. The LCD Display automatically returns to normal operation when you press a key on the keyboard. For energy conservation, turn your LCD Display OFF when it is not needed, or when leaving it unattended for long periods. The PowerSaver system operates with a VESA DPM compliant video card installed in your computer. Use the software utility installed on your computer to set up this feature.

PowerSaver (When used as a Network monitor)

State		Normal Operation	Power saving mode	Power off (Power-switch)
Power Indicator		On	Blinking	Off
Power Consumption	400CXN-2	250 watts	Less than 5 watts	Less than 1 watts
	460CXN-2	310 watts	Less than 5 watts	Less than 1 watts

PowerSaver (When used as a normal monitor)

State	Normal Operation	Power saving mode	Power off (Power-switch)
Power Indicator	On	Blinking	Off

Downloaded From TV-Manual.com Manuals

State		Normal Operation	Power saving mode	Power off (Power-switch)
Power Consumption	400CX-2	190 watts	Less than 2 watts	Less than 1 watts
	460CX-2	250 watts	Less than 2 watts	Less than 1 watts

Preset Timing Modes

If the signal transferred from the computer is the same as the following Preset Timing Modes, the screen will be adjusted automatically. However, if the signal differs, the screen may go blank while the power LED is on. Refer to the video card manual and adjusts the screen as follows.

Display Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock (MHz)	Sync Polarity (H/V)
IBM, 640 x 350	31.469	70.086	25.175	+/-
IBM, 640 x 480	31.469	59.940	25.175	-/-
IBM, 720 x 400	31.469	70.087	28.322	-/+
MAC, 640 x 480	35.000	66.667	30.240	-/-
MAC, 832 x 624	49.726	74.551	57.284	-/-
MAC, 1152 x 870	68.681	75.062	100.000	-/-
VESA, 640 x 480	37.861	72.809	31.500	-/-
VESA, 640 x 480	37.500	75.000	31.500	-/-
VESA, 800 x 600	35.156	56.250	36.000	+/+
VESA, 800 x 600	37.879	60.317	40.000	+/+
VESA, 800 x 600	48.077	72.188	50.000	+/+
VESA, 800 x 600	46.875	75.000	49.500	+/+
VESA, 848 x 480	31.020	60.000	33.750	+/+
VESA, 1024 x 768	48.363	60.004	65.000	-/-
VESA, 1024 x 768	56.476	70.069	75.000	-/-
VESA, 1024 x 768	60.023	75.029	78.750	+/+
VESA, 1152 x 864	67.500	75.000	108.000	+/+
VESA, 1280 x 768	47.776	59.870	79.500	-/+
VESA, 1280 x 960	60.000	60.000	108.000	+/+
VESA, 1280 x 1024	63.981	60.020	108.000	+/+
VESA, 1280 x 1024	79.976	75.025	135.000	+/+
VESA, 1360 x 768	47.712	60.015	85.500	+/+
VESA, 1366 x 768	47.712	59.790	85.500	+/+
VESA, 1920 x 1080	66.587	59.934	138.500	+/-
VESA, 1920 x 1080	67.500	60.000	148.500	+/-

Downloaded From TV-Manual.com Manuals

Horizontal Frequency

The time to scan one line connecting the right edge to the left edge of the screen horizontally is called the Horizontal Cycle and the inverse number of the Horizontal Cycle is called the Horizontal Frequency. Unit: kHz

Vertical Frequency

Like a fluorescent lamp, the screen has to repeat the same image many times per second to display an image to the user. The frequency of this repetition is called the Vertical Frequency or Refresh Rate. Unit: Hz

Downloaded From TV-Manual.com Manuals

Information

For a Better Display

Adjust the computer resolution and screen injection rate (refresh rate) on the computer as described below to enjoy the best picture quality. You can have an uneven picture quality on screen if the best picture quality is not provided for TFT-LCD.

- Resolution: 1920 x 1080
- Vertical frequency (refresh rate): 60 Hz

TFT-LCD panels manufactured by using advanced semiconductor technology with a precision of 1ppm (one millionth) and above is used for this product. But the pixels of RED, GREEN, BLUE and WHITE color seem to be bright sometimes or some of black pixels could be seen. This is not from bad quality and you can use it without any problems.

- For example, the number of TFT-LCD sub pixels contained in this product are 6,220,800.

When cleaning the monitor and the panel outside, please apply a small amount of water to a soft cloth.Rub softly when cleaning the LCD area.If excessive force is applied, you may stain it.

If you are not satisfied with the picture quality, you can get better quality of picture by performing the "**Auto Adjustment** function" in display screen that is appeared as window termination button is pressed. If there's still noise after the automatic adjustment, use the **Fine**/**Coarse** adjustment function.

When viewing a fixed screen for an extended period of time, a residual image or blurriness may appear. Change the mode to energy save or set a screensaver to move the picture when you need to be away from the monitor for an extended period of time.

PRODUCT INFORMATION (Image Retention Free)

What is Image Retention ?

Image retention may not occur when a LCD panel is operated under normal conditions.

Normal conditions are defined as continuously changing video patterns. When the LCD panel is operated for a long time with a fixed pattern (over 12 hours), there may be slight difference in voltage between electrodes that work the liquid crystal (LC) in a pixel. The voltage difference between electrodes increases with time, forcing the liquid crystal to lean. When this occurs, the previous image may be seen when the pattern is changed. To prevent this, the accumulated voltage difference must be decreased.

Downloaded From TV-Manual.com Manuals



Power Off, Screen Saver, or Power Save Mode

- Turn the power off for 4 hours after 20 hours in use
- Turn the power off for 2 hours after 12 hours in use
- Set the Monitor to power off with the PC Display Properties Power Scheme.
- Use a Screen saver if possible - Screen saver in one color or a moving image is recommended.

Change the Color Information periodically



Note

Use Two different colors

Rotate the Color Information with 2 different colors every 30 minutes.

Downloaded From TV-Manual.com Manuals

- Avoid using a combination of characters and background color with large difference in luminance.

  Avoid using Grey colors, which can cause Image retention easily.

  Avoid: Colors with big difference in luminance (Black & White, Grey)

Change the characters color periodically

- Use Bright colors with little difference in luminance.

  - Cycle : Change the characters color and background color every 30 minutes

- Every 30 minutes, change the characters with movement.

- Have the images and logo cycle periodically.

  - Cycle: Display moving image together with Logo for 60 seconds after 4 hours in use.

- The best way to protect your monitor from Image retention is to turn the Power off, or set your PC or System to operate a Screen Saver program when you are not using it. If these guidelines are not followed, it may affect your warranty.

Apply the Screen Scroll function on Product

- Apply the Screen Scroll function

  - Symptom: Horizontal Bar with Black Color move up and down.

Downloaded From TV-Manual.com Manuals

- Select method

- Instruction Guide : OSD Menu -> Set Up -> Safety Screen -> Screen Scroll
- Time Interval : 1 ~ 10 hours (Recommend : 1)
- Time Period : 1 ~ 5 second (Recommend : 5)

Apply the Screen Pixel function on Product

- Apply the Screen Pixel function

  - Symptom: Dot with Black Color move up and down.

- Select method

- Instruction Guide : OSD Menu -> Set Up -> Safety Screen -> Pixel
- Time Interval : 1 ~ 10 hours (Recommend : 1)
- Time Period : 10 ~ 50 seconds (Recommend : 50)

- Apply the Screen Bar function

  - Symptom: Horizontal / Vertical Bar with Black Color move up and down.

- Select method

- Instruction Guide : OSD Menu -> Set Up -> Safety Screen -> Bar
- Time Interval : 1 ~ 10 hours (Recommend : 1)
- Time Period : 10 ~ 50 seconds (Recommend : 50)

Apply the Screen Erasing function on Product

- Apply the Screen Erasing function

  - Symptom: 2 Vertical blocks move while erasing the display

Downloaded From TV-Manual.com Manuals



- Select method

- Instruction Guide : OSD Menu -> Set Up -> Safety Screen -> Eraser
- Time Interval : 1 ~ 10 hours (Recommend : 1)
- Time Period : 10 ~ 50 seconds (Recommend : 50)

Downloaded From TV-Manual.com Manuals

Appendix

Contact SAMSUNG WORLDWIDE

Note

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care center.

North America		
U.S.A	1-800-SAMSUNG (726-7864)	http://www.samsung.com/us
CANADA	1-800-SAMSUNG (726-7864)	http://www.samsung.com/ca
MEXICO	01-800-SAMSUNG (726-7864)	http://www.samsung.com/mx

Latin America		
ARGENTINA	0800-333-3733	http://www.samsung.com/ar
BRAZIL	0800-124-421 4004-0000	http://www.samsung.com/br
CHILE	800-SAMSUNG(726-7864)	http://www.samsung.com/cl
COLOMBIA	01-8000112112	http://www.samsung.com/co
COSTA RICA	0-800-507-7267	http://www.samsung.com/latin
ECUADOR	1-800-10-7267	http://www.samsung.com/latin
EL SALVADOR	800-6225	http://www.samsung.com/latin
GUATEMALA	1-800-299-0013	http://www.samsung.com/latin
HONDURAS	800-7919267	http://www.samsung.com/latin
JAMAICA	1-800-234-7267	http://www.samsung.com/latin
NICARAGUA	00-1800-5077267	http://www.samsung.com/latin
PANAMA	800-7267	http://www.samsung.com/latin
PUERTO RICO	1-800-682-3180	http://www.samsung.com/latin
REP. DOMINICA	1-800-751-2676	http://www.samsung.com/latin
TRINIDAD & TOBAGO	1-800-SAMSUNG (726-7864)	http://www.samsung.com/latin
VENEZUELA	0-800-100-5303	http://www.samsung.com/latin

Downloaded From TV-Manual.com Manuals

Europe

AUSTRIA	0810 - SAMSUNG (7267864, € 0.07/min)	http://www.samsung.com/at
BELGIUM	02 201 2418	http://www.samsung.com/be (Dutch) http://www.samsung.com/be_fr (French)
CZECH REPUBLIC	800 - SAMSUNG (800-726786) Distributor pro Českou republiku: Samsung Zrt., česká organizační složka, Oasis Florenc, Sokolovská394/17, 180 00, Praha 8	http://www.samsung.com/cz
DENMARK	8 - SAMSUNG (7267864)	http://www.samsung.com/dk
EIRE	0818 717 100	http://www.samsung.com/ie
FINLAND	30 - 6227 515	http://www.samsung.com/fi
FRANCE	01 4863 0000	http://www.samsung.com/fr
GERMANY	01805 - SAMSUNG (7267864, € 0.14/Min)	http://www.samsung.de
HUNGARY	06-80-SAMSUNG (726-7864)	http://www.samsung.com/hu
ITALIA	800-SAMSUNG (726-7864)	http://www.samsung.com/it
LUXEMBURG	02 261 03 710	http://www.samsung.com/lu
NETHERLANDS	0900-SAMSUNG (0900-7267864) (€ 0,10/Min)	http://www.samsung.com/nl
NORWAY	3 - SAMSUNG (7267864)	http://www.samsung.com/no
POLAND	0 801 1SAMSUNG (172678) 022 - 607 - 93 - 33	http://www.samsung.com/pl
PORTUGAL	808 20 - SAMSUNG (7267864)	http://www.samsung.com/pt
SLOVAKIA	0800-SAMSUNG (726-7864)	http://www.samsung.com/sk
SPAIN	902 - 1 - SAMSUNG(902 172 678)	http://www.samsung.com/es
SWEDEN	075 - SAMSUNG (726 78 64)	http://www.samsung.com/se
SWITZERLAND	0848 - SAMSUNG (7267864, CHF 0.08/min)	http://www.samsung.com/ch
U.K	0845 SAMSUNG (7267864)	http://www.samsung.com/uk

Downloaded From TV-Manual.com Manuals

CIS

ESTONIA	800-7267	http://www.samsung.com/ee
LATVIA	8000-7267	http://www.samsung.com/lv
LITHUANIA	8-800-77777	http://www.samsung.com/lt
KAZAKHSTAN	8-10-800-500-55-500	http://www.samsung.com/kz_ru
KYRGYZSTAN	00-800-500-55-500	
RUSSIA	8-800-555-55-55	http://www.samsung.ru
TADJIKISTAN	8-10-800-500-55-500	
UKRAINE	8-800-502-0000	http://www.samsung.ua
UZBEKISTAN	8-10-800-500-55-500	http://www.samsung.com/kz_ru

Asia Pacific

AUSTRALIA	1300 362 603	http://www.samsung.com/au
CHINA	800-810-5858 400-810-5858 010-6475 1880	http://www.samsung.com/cn
	HONG KONG:3698 - 4698	http://www.samsung.com/hk
INDIA	3030 8282 1-800-3000-8282 1800 110011	http://www.samsung.com/in
INDONESIA	0800-112-8888	http://www.samsung.com/id
JAPAN	0120-327-527	http://www.samsung.com/jp
MALAYSIA	1800-88-9999	http://www.samsung.com/my
NEW ZEALAND	0800 SAMSUNG(0800 726 786)	http://www.samsung.com/nz
PHILIPPINES	1-800-10-SAMSUNG (726-7864) 1-800-3-SAMSUNG (726-7864) 02-5805777	http://www.samsung.com/ph
SINGAPORE	1800-SAMSUNG (726-7864)	http://www.samsung.com/sg
THAILAND	1800-29-3232, 02-689-3232	http://www.samsung.com/th

Downloaded From TV-Manual.com Manuals

Asia Pacific

TAIWAN	0800-329-999	http://www.samsung.com/tw
VIETNAM	1 800 588 889	http://www.samsung.com/vn

Middle East & Africa

SOUTH AFRICA	0860-SAMSUNG (726-7864)	http://www.samsung.com/za
TURKEY	444 77 11	http://www.samsung.com/tr
U.A.E	800-SAMSUNG(726-7864) 8000-4726	http://www.samsung.com/ae

Terms

Dot Pitch	The image on a monitor is composed of red, green and blue dots. The closer the dots, the higher the resolution. The distance between two dots of the same color is called the 'Dot Pitch'. Unit: mm
Vertical Frequency	The screen must be redrawn several times per second in order to create and display an image for the user. The frequency of this repetition per second is called the Vertical Frequency or Refresh Rate. Unit: Hz Example: If the same light repeats itself 60 times per second, this is regarded as 60 Hz.
Horizontal Frequency	The time to scan one line connecting the right edge to the left edge of the screen horizontally is called the Horizontal Cycle. The inverse number of the Horizontal Cycle is called Horizontal Frequency. Unit: kHz
Interlace and Non-Interlace Methods	Showing the horizontal lines of the screen from the top to the bottom sequentially is called the Non-Interlace method while showing odd lines and then even lines in turn is called the Interlace method. The Non-Interlace method is used for the majority of monitors to ensure a clear image. The Interlace method is the same as that used in TVs.
Plug & Play	This is a function that provides the best quality screen for the user by allowing the computer and the monitor to exchange information automatically. This monitor follows the international standard VESA DDC for the Plug & Play function.
Resolution	The number of horizontal and vertical dots used to compose the screen image is called the 'resolution'. This number shows the accuracy of the display. A high resolution is good for performing multiple tasks as more image information can be shown on the screen.

Downloaded From TV-Manual.com Manuals

Example: If the resolution is 1920 x 1080, this means the screen is composed of 1920 horizontal dots (horizontal resolution) and 1080 vertical lines (vertical resolution).

Correct Disposal

Correct Disposal of This Product (Waste Electrical & Electronic Equipment) - Europe only

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

Correct disposal of batteries in this product - Europe only

(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

Note

The rechargeable battery incorporated in this product is not user replaceable. For information on its replacement, please contact your service provider.

Authority

Information in this document is subject to change without notice.

© 2009 Samsung Electronics Co., Ltd. All rights reserved.

Reproduction in any manner whatsoever without the written permission of Samsung Electronics Co., Ltd. is strictly forbidden.

Downloaded From TV-Manual.com Manuals

Samsung Electronics Co., Ltd. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Samsung is the registered trademark of Samsung Electronics Co., Ltd.; Microsoft, Windows and Windows NT are registered trademarks of Microsoft Corporation; VESA, DPM and DDC are registered trademarks of Video Electronics Standard Association; the ENERGY STAR® name and logo are registered trademarks of the U.S. Environmental Protection Agency (EPA). All other product names mentioned herein may be the trademarks or registered trademarks of their respective owners.

TruSurround XT, SRS and (●) Symbol are trademarks of SRS Labs, Inc.
TruSurround XT technology is incorporated under license from SRS Labs, Inc.

CALIFORNIA USA ONLY (Applicable for networking models only.)

This Perchlorate warning applies only to primary CR(Manganese Dioxide) Lithium coin cells in the product sold or distributed ONLY in California USA

"Perchloate Material - special handling may apply,
See www.dtsc.ca.gov/hazardouswaste/perchlorate."

Downloaded From TV-Manual.com Manuals